ZEBRONICS
ALWAYS AHEAD

2.1 Speaker

ZEB PLUTO 2

User Manual

www.zebronics.com

Thank you for purchasing the **ZEB-PLUTO 2** 2.1 Speaker. Please read the user manual carefully before usage & save it for future reference.

Note:

• *Avoid the usage of this speaker at the high temperature and high humidity environment.*

• *Avoid the self-disassembly of the product or it results in voiding the product's warranty.*

• *Turn off the speaker when the speaker is not in use.*

• *To know more about Terms and conditions for warranty policy, please visit*

   https://zebronics.com/pages/warranty-policy

Features
2.1 channel speaker
BT v5.0/AUX/FM/USB /mSD
RGB LED Lights
7.62cm (3") subwoofer
Volume controller
6 LED modes +1 off mode

Specifications
Output Power (RMS)
        Subwoofer   : 9 watts
        Satellites   : 2 x 3 watts
        Total   : 15 watts
Drivers
        Subwoofer   : 7.62 cm (3")
        Satellites   : 5.2 cm x 2

Impedance	
Subwoofer	: 3 ohm
Satellite	: 4 ohm
Frequency response	: 80Hz - 15kHz
S/N Ratio	: ≥ 65dB
Separation	: ≥ 60dB
File format support (USB/mSD)	: MP3
Line input	: 3.5mm
Max supported USB/ mSD memory size	: 32GB
FM frequency range	: 87.5 MHz -108MHz
BT name	: ZEB - PLUTO 2
BT version	: 5.0
Product Dimension (W x D x H)	
Subwoofer	: 13.4 x 13.7 x 13.8 cm
Satellite	: 8 x 8 x 10 cm
Net.Weight	: 860g

Package Content

Speaker	: 1 U
QR Code Guide	: 1 U

Control Panel Description

1. Volume knob with power on /off switch
2. Mode / LED Button.
3. Previous button / Volume -
4. Play/Pause button
5. Next / Volume + button
6. USB Port
7. mSD Slot
8. LED indicator

General Instructions
BT Mode:

Turn on the speaker, press **"LED/M"** button to switch to BT Mode. Switch ON BT on your phone or tablet and search for nearby BT devices, Search for the BT name **" ZEB PLUTO 2 "** and tap to connect it.

USB Mode & mSD mode:

The speaker automatically switches to USB input mode when a **USB** flash drive is inserted into the speaker. The songs from the USB audio source can be heard through the speaker (this mode isn't selectable on the speaker unless a mSD/ USB flash drive is connected). Single Press The **PREV** to switch to previous audio track and Single Press the **NEXT** button to switch to next audio track.

FM Radio:

Press the **LED/M** button to select **FM** mode. Long press Play pause button to initiate FM Scanning process. Once the scanning process is done, the Speaker automatically plays the First channel of the FM. Press **Prev** to switch to previous FM channel and Press **Next** to switch to next FM channel.

AUX-IN:

Press the **"LED/M"** button to select **AUX** mode. The speaker can be connected to an audio source using the inbuilt USB 3.5mm cable. Plug the USB connector to the Rated 5V Power source and connect the 3.5 mm Aux connector to an audio source. The songs from the audio source can be heard through the speaker.

LED LIGHTS Control

Using the integrated **LED/Mode** button. Press and hold the LED/Mode button. To switch the LED mode of the speaker. There are 6 LED Modes + One off mode available in the speaker.