




ZEBRONICS

ALWAYS AHEAD

Since 1997



IT & Gaming Peripherals • Sound Systems • Surveillance • Mobile & Lifestyle Accessories

CELEBRATING
21st YEAR
excellence • quality • reliability

 **WINNER 75** INDUSTRY AWARDS



ZEB-PUNCH
Portable BT Speaker

- Portable Design
- Call function
- Passive Drivers for enhanced bass
- Volume/Media Control
- Dual Drivers
- Textured Leather Finish





- BT
- FM Radio
- AUX
- USB
- Micro SD Card

Different LED Indications


- Charging Indication: Red LED glows
- Full Charge Indication: Red LED Turns OFF





BT Connectivity

- Turn on the speaker.
- Make sure the speaker is in BT Mode.
- Search for nearby BT devices in your mobile.
- Tap on BT Name “ZEB-PUNCH” to connect.



Press Once: Next Song

Press Once: Volume -

Press Once: Volume +

Press Once: Previous Song


Press Once: Change Mode

Press Once: Play/Pause

Press & Hold: Turn on-off the speaker

FM Radio

- Switch the Speaker to FM Mode by pressing the Mode button.
- Connect the AUX cable to the speaker and leave the other end free (This cable will act as an antenna).
- Press the Play/Pause button once to scan the available FM channels.
- Once the scanning is done, the speaker will start playing from first saved channel.



Press Once: Next FM Channel

Press Once: Volume -

Press Once: Volume +

Press Once: Previous FM Channel

Press Once: Change Mode

Press Once: Scan for available FM Channels

Press & Hold: Turn on-off the speaker

AUX Mode

- Once the speaker is in AUX Mode, connect the AUX cable to the speaker & connect the other end 3.5mm jack to a audio source (Eg. Computer, mobile).
- Now the songs played by the audio source can be heard through the speaker.



Press Once: Volume -

Press Once: Volume +


Press Once: Change Mode

Press Once: Mute/Unmute

Press & Hold: Turn on-off the speaker

USB/Micro SD Card Mode

- When the speaker is on, insert the USB/Micro SD card to the speaker.
- The speaker will detect the USB/Micro SD card automatically & play the songs from the USB/Micro SD card.



Press Once: Next Song

Press Once: Volume -

Press Once: Volume +

Press Once: Previous Song

Press Once: Change Mode

Press Once: Play/Pause

Press & Hold: Turn on-off the speaker

Call Function

- When the speaker is connected to a mobile via BT.
- Press the play-pause key to answer/hung up a call.
- Press & Hold the Play-Pause key once to reject an incoming call.
- Double Press the Play/Pause key to redial the last number dialed.

Note: Call function will work only in BT Mode



Press Once: Volume -

Press Once: Volume +

Press Once: Change Mode

Press Once: Answer/hung up a call

Press & Hold: Reject an incoming call

Double Press: Redial the last number dialed

Specifications

ZEB-PUNCH

- Output Power (RMS): 3W x 2
- BT Version: 4.2
- Driver Size: 5.08cm(2") x 2
- Max Supported USB/Micro SD memory size: 32GB
- Playback time: 2- 3 hrs
- Product Dimension (WxDxH): 217 x 70 x 67 mm
- Net. Weight: 570g



Package Contents

- Speaker: 1 unit
- Charging Cable: 1 unit
- AUX Cable: 1 unit
- User manual: 1 unit



Thank You



www.zebronics.com