




ZEBRONICS

ALWAYS AHEAD

Since 1997



IT & Gaming Peripherals • Sound Systems • Surveillance • Mobile & Lifestyle Accessories

CELEBRATING
21st YEAR
excellence • quality • reliability

 **WINNER**
75 INDUSTRY
AWARDS



ZEB-VOGUE
Portable BT Speaker

- Compact & Portable Design
- Premium Finish
- Built-in Rechargeable Battery
- Dual Drive Speaker
- Playback Time: 5 hrs
- Call Function
- Volume/Media Control
- Dedicated On/Off Switch



Connectivity

- BT
- FM Radio
- AUX
- USB
- Micro SD Card



Different LED Indications

- Charging Indication: Red LED glows
- Full Charge Indication: Red LED Turns OFF



Mode Change Button

Play/Pause Key

Volume/Media Control



Charging/AUX Port

On-Off Switch

USB

Micro SD Card Slot

BT Connectivity

- Turn on the speaker.
- Make sure the speaker is in BT Mode.
- Search for nearby BT devices in your mobile.
- Tap on BT Name “ZEB-VOGUE” to connect.



Change Mode

•Press once: Previous Song
•Press & Hold: Volume -

•Play/Pause

•Press once: Next Song
•Press & Hold: Volume +

FM Radio

- Switch the Speaker to FM Mode by pressing the Mode button.
- Connect the charging cable to the speaker and leave the other end free (This cable will act as an antenna).
- Press & hold the Play/Pause button for 3 seconds to scan the available FM channels.
- Once the scanning is done, the speaker will start playing from first saved channel.



•Press Once: Change Mode

•Press Once: Previous FM Channel

•Press & Hold: Volume -

•Press & Hold: Scans for available FM Channels


•Press Once: Mute/Unmute

•Press Once: Next FM Channel

•Press & Hold: Volume +


AUX Mode

- Once the speaker is in AUX Mode, connect the charging cable to the speaker & connect the 3.5mm jack to a audio source (Eg. Computer, mobile).
- Now the songs played by the audio source can be heard through the speaker.



USB/Micro SD Card Mode

- When the speaker is on, insert the USB/Micro SD card to the speaker.
- The speaker will detect the USB/Micro SD card automatically & play the songs from the USB/Micro SD card.



Call Function

- When the speaker is connected to a mobile via BT.
- Press the play-pause key to answer/hung up a call.
- Double Press the Play/Pause key to redial the last number dialed.
- Press & Hold the Call Function to reject an incoming call.



•Press Once: Change Mode

•Press & Hold: Volume -

•Press Once: Answer/hung up a call

•Press & Hold: Reject an incoming call

•Double Press: Redial the last number dialed

•Press & Hold: Volume +

Specifications

ZEB-VOGUE

- Output Power (RMS): 3W x 2
- BT Version: 4.2
- Driver Size: 45mm x 2
- Max Supported USB/Micro SD memory size: 32GB
- Playback time: 5hrs
- Product Dimension (WxDxH): 213 x 60.3 x 66.75 mm
- Net. Weight: 354g

Package Contents

- Speaker: 1 unit
- Charging/3.5mm AUX Cable: 1 unit
- User manual: 1 unit



Thank You



www.zebronics.com