




# ZEBRONICS

ALWAYS AHEAD

Since 1997



IT & Gaming Peripherals • Sound Systems • Surveillance • Mobile & Lifestyle Accessories

CELEBRATING  
**22<sup>nd</sup> YEAR**  
excellence • quality • reliability

 WINNER  
**82** INDUSTRY  
**AWARDS**

**MRP** ₹ 1499/-



ZEB-ACTION  
Portable BT Speaker

- Compact in Size
- TWS Function
- 12hrs\* playback time
- Call Function
- Fabric Finish
- Available in 3 Colors
- Media / Volume control
- Built-in Rechargeable battery

\*at 50% Volume




- BT
- USB
- Micro SD Card
- FM
- AUX

## LED Indications

- Charging Indication: Red LED glowing continuously
- Full Charge Indication: Red LED turns off

# Keys & Ports

ZEB-ACTION



## BT Connectivity

- Turn on the speaker & Make sure that the speaker is in BT Mode
- Search for the nearby BT Devices in your phone.
- Tap on the BT Name “ZEB-ACTION” to connect it.



Press once: Play/Pause  
Press & Hold: Turn on-off the speaker

Press once: Next song  
Press & Hold: Volume +

Press once: Change Mode

Press once: Previous song  
Press & Hold: Volume -

## USB/Micro SD Card Mode

- When the speaker is on, insert the USB/Micro SD card to the speaker.
- The speaker will detect the USB/Micro SD card automatically & play the songs from the Micro SD card.



Press once: Play/Pause  
Press & Hold: Turn on-off the speaker

Press once: Next song  
Press & Hold: Volume +

Press once: Change Mode

Press once: Previous song  
Press & Hold: Volume -

## FM Radio

- Switch the speaker to FM mode.
- Connect the micro USB cable to the micro USB port of the speaker and leave the other end free (this cable will act as the FM antenna).
- Long press the mode button once to scan the FM channels.
- Once the scanning is done, the speaker will start playing from first scanned channel.



Press once: Play/Pause

Press & Hold: Turn on-off the speaker

Press once: Next FM Channel

Press & Hold: Volume +


Press once: Change Mode

Press once: Previous FM Channel

Press & Hold: Volume -

## AUX Mode

- Once the speaker is in AUX Mode, connect one end of the AUX cable to the speaker & connect the other end to an audio source (Eg. Computer, mobile).
- Now the songs played by the audio source can be heard through the speaker.



Press once: Mute/Unmute  
Press & Hold: Turn on-off the speaker

Press & Hold: Volume +

Press once: Change Mode

Press & Hold: Volume -

## Call Function

- When the speaker is connected to a mobile via BT.
- Press the on-off key to answer/hung up a call.
- Double Press the on-off key to redial the last number dialed.
- Press & hold the on-off key to reject an incoming call.



Press once: answer/hung up a call  
Press & Hold: Reject an incoming call  
Double press: Redial the last number

Press & Hold: Volume +

Press once: Change Mode

Press & Hold: Volume -

- TWS mode requires 2 nos. of ZEB-ACTION speakers. When the speakers are in BT mode, Press & hold the “Mode” key on any one speaker. (you would hear a tone indicating that the TWS mode is activated.)
- After few seconds, the speakers will automatically get paired with each other
- Now, Scan for nearby BT Devices in your phone.
- Tap on the BT Name “ZEB-ACTION” to connect it.



## Specifications

ZEB-ACTION

- Output Power (RMS): 10W (5W+5W)
- BT Version : 5.0
- Driver Size: 45mm x 2
- S/N Ratio:  $\geq 90$ dB
- Separation:  $\geq 45$ dB Max
- Charging time: 5-6 hrs
- Playback time: 12 hrs\*
- Product Dimension (Dia x H): 68.1 x 159.8 mm
- Net. Weight: 384g

## Package Contents

- Speaker :1 unit
- Charging cable :1 unit
- User Manual :1 unit

Thank You



[www.zebronics.com](http://www.zebronics.com)