




ZEBRONICS

ALWAYS AHEAD

Since 1997



IT & Gaming Peripherals • Sound Systems • Surveillance • Mobile & Lifestyle Accessories

CELEBRATING
21st YEAR
excellence • quality • reliability

 **WINNER 75** INDUSTRY AWARDS



ZEB-GLORY
Portable Wireless BT Speaker

- Classy Design
- Wooden Finish
- 10hrs* Playback Time
- Volume/Media Control
- Built in Rechargeable Battery



- BT
- Micro SD Card
- FM

Different LED Indications

- Charging Indication: Red LED glows
- Full Charge Indication: Red LED turns off





BT Connectivity


- Turn on the speaker.
- Make sure that the speaker is on BT Mode
- Search for nearby BT devices in your mobile.
- Tap on BT Name “ZEB-GLORY” to connect.

Press Once: Next Song

Press Once: Play/Pause

Press Once: Change Mode
Press & Hold: Turn On-Off speaker

Press Once: Previous Song



Rotate Anti Clockwise: Vol –
Rotate Clockwise: Vol +

Micro SD Card Mode

- When the Speaker is on, Insert the Micro SD card to the speaker.
- The speaker detects the mSD card automatically and play the songs from it.

Press Once: Next Song

Press Once: Play/Pause

Press Once: Change Mode
Press & Hold: Turn On-Off speaker

Press Once: Previous Song



Rotate Anti Clockwise: Vol -
Rotate Clockwise: Vol +

FM Radio Mode


- Switch the speaker to FM Mode by pressing the Mode key
- Press the Play/Pause key once to scan to the available FM Channel
- Once the scanning is done, the speaker will start playing the first saved FM Channel

Press Once: Next FM Channel

Press Once: Auto Scan
FM Channels

Press Once: Change Mode
Press & Hold: Turn On-Off speaker

Press Once: Previous FM Channel



Rotate Anti Clockwise: Vol -
Rotate Clockwise: Vol +

- BT Version: 4.2
- Driver Size: 40mm
- Supported mSD Memory Size: 32GB
- Supported Audio Format: MP3
- Playback time: 10hrs*
- Product Dimension: 95 x 59 x 66mm
- Net. Weight: 220g

Package Contents

- Speaker: 1 unit
- Charging Cable: 1 Unit
- User Manual: 1 unit



Thank You



www.zebronics.com