




ZEBRONICS

ALWAYS AHEAD

Since 1997



IT & Gaming Peripherals • Sound Systems • Surveillance • Mobile & Lifestyle Accessories

CELEBRATING
22nd YEAR
excellence • quality • reliability

 **WINNER**
82 **INDUSTRY AWARDS**



ZEB-PEAK
Portable BT Speaker

- Compact in size
- TWS Function
- LED Lights
- Call Function
- Media / Volume control
- Built-in Rechargeable battery

- Wireless BT
- USB
- Micro SD
- FM
- AUX

LED Indications

- Charging Indication: Red LED glowing continuously
- Full Charge Indication: Red LED turns off



BT Connectivity

- Turn on the speaker & Make sure that the speaker is in BT Mode
- Search for the nearby BT Devices in your phone.
- Tap on the BT Name “ZEB-PEAK” to connect it.



Press once: Change Mode

Press once: Play/Pause
Press & Hold: Turn on-off the speaker

Press once: Change LED mode

Press once: Next song
Press & Hold: Volume +

Press once: Previous song
Press & Hold: Volume -

USB/Micro SD Card Mode

- When the speaker is on, insert the USB/Micro SD card to the speaker.
- The speaker will detect the USB/Micro SD card automatically & play the songs from the Micro SD card.



Press once: Change Mode

Press once: Play/Pause
Press & Hold: Turn on-off the speaker

Press once: Change LED mode

Press once: Next song
Press & Hold: Volume +

Press once: Previous song
Press & Hold: Volume -

FM Radio

- Switch the speaker to FM mode.
- Connect the micro USB cable to the micro USB port of the speaker and leave the other end free (this cable will act as the FM antenna).
- Press the play/pause key once to scan the FM channels.
- Once the scanning is done, the speaker will start playing from first scanned channel.



Press once: Change Mode

Press once: Auto scan available FM Channel
Press & Hold: Turn on-off the speaker

Press once: Change LED mode

Press once: Next FM Channel
Press & Hold: Volume +

Press once: Previous FM Channel
Press & Hold: Volume -

AUX Mode

- Once the speaker is in AUX Mode, connect one end of the AUX cable to the speaker & connect the other end to an audio source (Eg. Computer, mobile).
- Now the songs played by the audio source can be heard through the speaker.



Press once: Change Mode

Press once: Auto scan available FM Channel
Press & Hold: Turn on-off the speaker

Press once: Change LED mode

Press & Hold: Volume +

Press & Hold: Volume -

Call Function

- When the speaker is connected to a mobile via BT.
- Press the Play/Pause key to answer/hung up a call.
- Double Press the Play/Pause key to redial the last number dialed.
- Press & hold the Play/Pause key to reject an incoming call.



Press once: Change Mode

Press once: answer/hung up a call

Press & Hold: Reject an incoming call

Double press: Redial the last number

Press once: Change LED mode

Press & Hold: Volume +

Press & Hold: Volume -

- TWS mode requires 2 nos. of ZEB-PEAK speakers. When the speakers are in BT mode, Press & hold the “Mode” key on any one speaker. (you would hear a tone indicating that the TWS mode is activated.)
- After few seconds, the speakers will automatically get paired with each other
- Now, Scan for nearby BT Devices in your phone.
- Tap on the BT Name “ZEB-PEAK” to connect it.



Specifications

ZEB-PEAK

- Output Power (RMS): 5W
- BT Version : 4.2
- Driver Size: 45mm
- S/N Ratio: ≥ 80 dB
- Charging time: 3 hrs
- Playback time: 6 hrs*
- Product Dimension (W x D x H): 75 x 75 x 157mm
- Net. Weight: 384g

Package Contents

- Speaker :1 unit
- Charging cable :1 unit
- User Manual :1 unit

Thank You



www.zebronics.com