




ZEBRONICS

ALWAYS AHEAD

Since 1997



IT & Gaming Peripherals • Sound Systems • Surveillance • Mobile & Lifestyle Accessories

CELEBRATING
21st YEAR
excellence • quality • reliability

 **WINNER 75** INDUSTRY AWARDS



ZEB-PRISTINE 4
4.1 Speaker

MRP ₹ 4999/-

- 4.1 Speaker
- Stylish Front Panel with dual texture finish
- Soft touch rubber finish buttons
- Satellites with fabric finish
- RGB Strip with on/off control
- LED Display
- Remote Control
- Volume, Bass & Treble Control



- BT
- USB
- SD Card
- FM
- AUX









BT Connectivity

- Turn on the speaker.
- Make sure the speaker is in BT Mode.
- Search for nearby BT devices in your mobile.
- Tap on BT Name “ZEB-PRISTINE 4” to connect.




USB/SD Card Mode

- When the speaker is on, insert a Pendrive/SD Card to the speaker.
- The speaker will detect the Pendrive/SD Card automatically & play the songs from the it.




FM Radio

- Switch the speaker to FM Mode.
- Press & Hold the Play/Pause key to auto scan the available FM Channel.
- Once the scanning is done, the speaker will start playing the first saved FM Channel.



AUX Mode

- Once the speaker is in AUX Mode, connect the AUX cable to the speaker & connect the other end to a audio source (Eg. Computer, mobile).
- Now the songs played by the audio source can be heard through the speaker.



- Output Power (RMS)
Subwoofer: 25 watts
Satellite : 10 watts x 4
Total: 65 watts
- Driver Size
Subwoofer: 10.16 cm (5") x 1
Satellite: 7.62 cm (3") x 4
- File format support (USB/SD): MP3
- Line input: 2ch RCA
- Max supported memory size (USB/SD): 32GB
- BT version: 4.2
- Product Dimension (W x D x H)
Subwoofer: 200 x 286 x 207 mm
Satellite: 100 x 102 x 153 mm
- Net. Weight
Subwoofer: 3.5kg
Satellite: 500g x 4
Total: 5.5kg

- Subwoofer: 1 unit
- Satellite: 4 units
- Remote: 1 unit
- User manual: 1 unit
- Input cable: 1 unit

Thank You



www.zebronics.com