

ZEBRONICS

ALWAYS AHEAD

Since 1997

IT Peripherals • Multimedia Speakers
LED TV • Surveillance



55 | Winner of
Industry Awards





Product Demo

SHARK

BT RUCF



USP

- Floor standing satellites
- Floating front panel
- Multicolor LED light – manual and auto mode
- Dual mic input, 6.3mm
- Dual driver satellites, mid range and tweeter
- Loud sound – 180watts RMS
- 20.3cms(8) subwoofer driver
- Rich bass and treble reproduction
- Multiple connectivity option



USP

- Floor standing satellites
- Floating front panel
- Multicolor LED light – manual and auto mode
- Dual mic input, 6.3mm
- Dual driver satellites, mid range and tweeter
- Loud sound – 180watts RMS
- 20.3cms(8) subwoofer driver
- Rich bass and treble reproduction
- Multiple connectivity option



Connectivity

- Bluetooth – 10meters range
- USB pendrive(32GB max)
- SD/MMC card(32GB max)
- FM Radio
- 5.1/DVD input
- Aux input
- Mic input

Basic Operation

- Switch on/off – Back panel power button
- Volume knob rotate – works in all modes
- Multimedia buttons – to control the media
- Volume knob press – to adjust individual volumes and mic volume/echo

Basic Operation

SHARK
BT RUCF



Front panel



Power Switch

LED Display

Input

Next

Multicolor LED Light
To change – LED
button on remote

Floating panel
Volume knob

Connect the
satellites here

5.1 input

FM Antenna
Aux Input

SD/MMC

Mic 2

Back panel

Remote control



Aux Mode

- Connect the aux-in cable on the back panel
- Connect the other cable end to the source
- Select aux mode with input button
- Buttons operation as below



Mute

Front panel

Input

Volume knob
Rotate - vol+/-
Press – menu



Aux Input

Back panel

Controls

5.1/DVD Mode

- Connect the 5.1 cables on the back panel
- Connect the other cable ends to the source
- Select DVD mode with input button
- Buttons operation as below



Mute

Input

Volume knob
Rotate - vol+/-
Press – menu

Front panel



5.1 input

Back panel

Controls

Bluetooth Mode

- Press the "input" button till display shows bluetooth mode
- Search for speaker "ZEB-SHARK" from the device
- Buttons operation as below



Previous

Play/Pause

Input

Next

Volume knob
Rotate - vol+/-
Press – menu

Front panel




Speaker connected

Controls

USB Mode

- Connect USB pendrive – 32GB max
- Speaker will automatically switch to USB mode
- If already connected then press the “input” button till display shows USB mode
- Buttons operation as below



Front panel

Controls

SD/MMC Mode

- Connect SD/MMC memory card – 32GB max
- Speaker will automatically switch to SD/MMC mode
- If already connected then press the “input” button till display shows SD mode
- Buttons operation as below



Front panel

Controls

FM Mode

- Connect the bundled FM antenna in the back panel
- press the "input" button till display shows FM mode
- Buttons operation as below



Previous station

Scan

Front panel

Input

Next station

Volume knob
Rotate - vol+/-
Press – menu



FM Antenna

Back panel

Controls

Specifications

- Power – 80w+20wx5 RMS
Total 180watts RMS
- Driver – 20.3cms(8) sub
7.6(3)+3.8cms(1.5) sat

Package content

- Subwoofer - 1no
- Satellites – 5nos
- Remote control
- FM Antenna
- Input cables
- Satellite interconnect
- User manual

Package





Thank You



www.zebronics.com

