

# ZEBRONICS

ALWAYS AHEAD

Since 1997

IT Peripherals • Multimedia Speakers  
LED TV • Surveillance



# 55

Winner of  
**Industry Awards**



# Product Demo

WHALE  
BT RUCF



 ZEBRONICS

## USP

- Floating front panel with LED display
- Blue LED light
- Dual mic input, 6.3mm
- Dual driver satellites, mid range and tweeter
- Loud sound – 180watts RMS
- 20.3cms(8) subwoofer driver
- Rich bass and treble reproduction
- Multiple connectivity option

# Connectivity


- Bluetooth – 10meters range
- USB pendrive(32GB max)
- SD/MMC card(32GB max)
- FM Radio
- 5.1/DVD input
- Aux input
- Mic input

# Basic Operation


- Switch on/off – Back panel power button
- Volume knob – works in all modes
- Input button – works in all modes
- Multimedia buttons – to control the media
- 2.1/5.1 button - to switch between 2.1 and 5.1 mode
- Menu button – to adjust individual volumes and mic volume/echo
- Mute
- Repeat

# Basic Operation

**WHALE**  
BT RUCF



Front panel



Back panel

# Remote control



# Aux Mode

- Connect the aux-in cable on the back panel
- Connect the other cable end to the source
- Select aux mode with input button
- Buttons operation as below



Input

Mute

Mute

5.1/2.1

Menu

Volume knob

Front panel



Aux-in

Back panel

## Controls

# 5.1/DVD Mode

- Connect the 5.1 cables on the back panel
- Connect the other cable ends to the source
- Select DVD mode with input button
- Buttons operation as below



Input

Mute


Mute

5.1/2.1

Menu

Volume knob

Front panel



5.1 input

Back panel

## Controls

# Bluetooth Mode

- Press the "input" button till display shows bluetooth mode
- Search for speaker "ZEB-WHALE" from the device
- Buttons operation as below



Front panel




Speaker connected

## Controls

# USB Mode

- Connect USB pendrive – 32GB max
- Speaker will automatically switch to USB mode
- If already connected then press the “input” button till display shows USB mode
- Buttons operation as below



Front panel

## Controls

# SD/MMC Mode

- Connect SD/MMC memory card – 32GB max
- Speaker will automatically switch to SD/MMC mode
- If already connected then press the “input” button till display shows SD mode
- Buttons operation as below



Front panel

## Controls

# FM Mode

- Connect the bundled FM antenna in the back panel
- press the "input" button till display shows FM mode
- Buttons operation as below



Previous channel  
Long press – fine tune

Input  
Next channel  
Long press – fine tune  
Auto Scan channels

Mute

5.1/2.1  
Menu  
Volume knob

Front panel



FM Antenna

Back panel

## Controls

## Specifications

- Power – 80w+20wx5 RMS  
Total 180watts RMS
- Driver – 20.3cms(8) sub  
7.6(3)+3.8cms(1.5) sat

## Package content

- Subwoofer - 1no
- Satellites – 5nos
- Remote control
- FM Antenna
- Input and output cables
- User manual

## Package





# Thank You



[www.zebronics.com](http://www.zebronics.com)

