




ZEBRONICS

ALWAYS AHEAD

Since 1997



IT & Gaming Peripherals • Sound Systems • Surveillance • Mobile & Lifestyle Accessories

CELEBRATING
22nd YEAR
excellence • quality • reliability

 **WINNER**
82 **INDUSTRY AWARDS**



MRP ₹ 27999/-

ZEB-MOVING MONSTER 2X10 PLUS DJ Speaker

- Karaoke with Recording function (Aux Input)
- LED display
- LED lights with On/Off function
- 2 way speaker
- 25.4cm(10") x 2 full range speaker
- Remote control
- Two Wireless MIC
- Built-in rechargeable battery
- 4 band Equalizer
- USB Charging for mobile/tablet
- 7 Magic Voice for Mic input
- Handle with wheels

Connectivity

ZEB-BT11400RUCFO

- BT
- USB
- FM
- AUX
- 2 x Mic

Keys & Ports

ZEB-MOVING MONSTER 2X10 PLUS





BT Connectivity

- Turn on the speaker & Make sure that the speaker is in BT Mode
- Search for the nearby BT Devices in your phone.
- Tap on the BT Name “ZEB-MOVING MONSTER 2X10 PLUS ” to connect it.

Press once: Next Song

Press once: Select Preferred magic mic mode

Press once: Play/Pause

Press once: Previous Song



Press once: Start recording

Press once: turn on speaker

Press once: Change Mode

Press once: Turn on-off mic priority

USB Mode

- When the speaker is on, insert the USB to the speaker.
- The speaker will detect the USB automatically & play the songs from the USB.

Press once: Next Song

Press once: Select Preferred magic mic mode

Press once: Play/Pause

Press once: Previous Song



Press once: Start recording

Press once: turn on speaker

Press once: Change Mode

Press once: Turn on-off mic priority

FM Radio

- Switch the speaker to FM mode.
- Press & Hold the play/pause key to scan the FM channels.
- Once the scanning is done, the speaker will start playing from first scanned channel.

Press once: Next FM Channel

Press once: Start recording



Press once: turn on speaker

Press once: Auto scan available FM Channel

Press once: Change Mode

Press once: Previous FM Channel

Press once: Turn on-off mic priority

AUX Mode

- Once the speaker is in AUX Mode, connect one end of the AUX cable to the speaker & connect the other end to an audio source (Eg. Computer, mobile).
- Now the songs played by the audio source can be heard through the speaker.



Wireless Mic

- Insert two AA batteries to the Mic.
- Turn on the Mic & the Mic would start to function.

Wired Mic

- Insert the wired mic jack to the Microphone input of the Speaker
- Turn on the Mic & the Mic would start to function.

- Driver Size
 - Full range : 25.4cm (10") x 2
 - Tweeter: 7.62 cm (3") x 2
- Frequency response: 40Hz-18kHz
- S/N Ratio: ≥ 70 dB
- File format support (USB): MP3/WMA/WAV/FLAC
- Line input: 3.5mm
- Max supported USB memory size: 64GB
- Charging time: 6hrs
- Playback time: 6hrs *
- BT name: ZEB-MOVING MONSTER 2X10 +
- BT version: 2.1+ EDR
- Product Dimension: 310 x 270 x 878 mm (W x D x H)
- Net. Weight: 14.2kg

Package Contents

ZEB-MOVING MONSTER 2X10 PLUS

- DJ Speaker :1 unit
- Power Cord :1 unit
- Remote control :1 unit
- Wireless MIC :2 units
- FM Antenna :1 unit
- User manual :1 unit

Thank You



www.zebronics.com