




ZEBRONICS

ALWAYS AHEAD

Since 1997



IT & Gaming Peripherals • Sound Systems • Surveillance • Mobile & Lifestyle Accessories

CELEBRATING
22nd YEAR
excellence • quality • reliability



 **WINNER**
82 **INDUSTRY AWARDS**



ZEB-BT11400RUCFO
Tower Speaker

- 2.0 Tower Speaker
- Optical input
- LED Display
- 3 way speakers (10"- Subwoofer,4"-Mid and 1"-Tweeter drivers)
- Karaoke / Recording function
- Dual microphone input jacks
- Two wireless Mic
- Remote Control

- BT
- USB
- Micro SD
- FM
- AUX
- OPTICAL input
- 2 x Mic





BT Connectivity

- Turn on the speaker & Make sure that the speaker is in BT Mode
- Search for the nearby BT Devices in your phone.
- Tap on the BT Name “ZEB-BT11400RUCFO” to connect it.



Press Once: Next song
Press & Hold: Volume +

Press Once: Select Preferred equalizer

Press Once: Play/Pause

Press Once: Previous song
Press & Hold: Volume -

Press Once: Change Mode

USB/Micro SD Card Mode

- When the speaker is on, insert the USB/Micro SD card to the speaker.
- The speaker will detect the USB/Micro SD card automatically & play the songs from the USB/Micro SD card.



Press Once: Next song
Press & Hold: Volume +

Press Once: Select repeat mode

Press Once: Select Preferred equalizer

Press Once: Play/Pause

Press Once: Change Mode

Press Once: Previous song
Press & Hold: Volume -

FM Radio

- Switch the speaker to FM mode.
- Press & Hold the play/pause key to scan the FM channels.
- Once the scanning is done, the speaker will start playing from first scanned channel.



Press Once: Next FM Channel
Press & Hold: Volume +

Press Once: Select repeat mode

Press Once: Select Preferred equalizer

Press & Hold: Auto scan available
FM Channels

Press Once: Previous FM Channel
Press & Hold: Volume -

Press Once: Change Mode

AUX/Optical Mode

- Once the speaker is in AUX/Optical Mode, connect one end of the AUX or Optical cable to the speaker & connect the other end to an audio source (Eg. Computer, mobile).
- Now the songs played by the audio source can be heard through the speaker.



Press Once: Change Mode

Press & Hold: Volume +

Press & Hold: Mute/Unmute

Press & Hold: Volume -

Wireless Mic

- Insert two AA batteries to the Mic.
- Turn on the Mic & the Mic would start to function.

Wired Mic

- Insert the wired mic jack to the Microphone input of the Speaker
- Turn on the Mic & the Mic would start to function.

- Driver Size
 - Subwoofer: 25.4cm (10") x 2
 - Mid: 10.16cm (4") x 2
 - Tweeter: 2.54cm (1") x 2
- Frequency response: 40Hz- 18kHz
- File format support(USB/mSD): MP3 / WMA / WAV
- Line input: 2ch RCA & Optical Input
- Max supported USB/mSD memory size: 32GB
- FM frequency range: 87.5MHz - 108MHz
- BT Name: ZEB-BT11400 RUCFO
- BT version: 4.2
- Product Dimension: 178 x 344 x 900 mm (W x D x H)
- Net. Weight
 - with amplifier: 11.65 Kg (Approx.)
 - w/o amplifier: 10.40 Kg (Approx.)

Package Contents

ZEB-BT11400RUCFO

- Tower Speaker :2 units
- Remote control :1 unit
- Wireless Mic :2 units
- Input Cable :1 unit
- Speaker wire :1 unit
- Antenna cable :1 unit
- Power cord :1 unit
- User manual :1 unit

Thank You



www.zebronics.com