




# ZEBRONICS

ALWAYS AHEAD

Since 1997



IT & Gaming Peripherals • Sound Systems • Surveillance • Mobile & Lifestyle Accessories

CELEBRATING  
**21<sup>st</sup>** YEAR  
excellence • quality • reliability

 **WINNER 75** INDUSTRY AWARDS



MRP ₹ 11999/-



ZEB-TRX12L  
Trolley DJ Speaker

- Trolley Design
- Built-in Rechargeable Battery
- 10hrs\* playback time
- 2 Way Speaker: 12" Full Range Drive & 1" Tweeter
- Wireless Mic
- Recording
- LED Display
- RGB Lights with on-off Switch
- Remote Control
- Supports External Battery


- BT
- USB
- SD Card
- FM
- AUX
- 1 x Mic
- 1 x Guitar In



# Keys & Ports


ZEB-TRX12L






## BT Connectivity

- Turn on the speaker.
- Make sure the speaker is in BT Mode.
- Search for nearby BT devices in your mobile.
- Tap on BT Name “ZEB-TRX12L” to connect.



## USB/SD Card Mode

- When the speaker is on, insert a Pendrive/SD Card to the speaker.
- The speaker will detect the Pendrive/SD Card automatically & play the songs from the it.



## FM Radio


- Switch the speaker to FM Mode.
- Press the Play/Pause key once to auto scan the available FM Channel.
- Once the scanning is done, the speaker will start playing the first saved FM Channel.

Note: For better FM Reception, please use the provide FM antenna



## AUX Mode

- Once the speaker is in AUX Mode, connect the AUX cable to the speaker & connect the other end to a audio source (Eg. Computer, mobile).
- Now the songs played by the audio source can be heard through the speaker.



## Wireless Mic

- Insert two AA batteries to the Mic.
- Turn on the Mic & the Mic would start to function.

## Wired Mic

- Insert the wired mic jack to the Microphone input of the Speaker
- Turn on the Mic & the Mic would start to function.

- When the speaker is on, Insert a Pendrive to the USB slot of the speaker.
- Using the remote, Press the record key once to start recording.
- To stop recording & to play the recorded file, Press Rec. Play on the remote.

Note: Songs that is being played by the speaker will be paused while recording.



→ Press Once: To start Recording

→ Press Once: To stop recording & to play the recorded file

- Driver Size  
Full range: 30.48cm(12")  
Tweeter: 2.54cm(1")
- File Format Support(USB/SD): MP3, WMA, WAV
- Line Input: 3.5mm
- Max Supported USB/SD Memory Size: 32GB
- BT Name: ZEB-TRX12L
- BT Version: 4.2
- Product Dimension (W x D x H): 363 x 336 x 585 mm
- Net. Weight: 12.8kg

- Speaker: 1 unit
- Remote: 1 unit
- Wireless Mic: 1 unit
- User manual: 1 unit
- Input cable: 1 unit
- Power adapter: 1 unit
- Microphone hook: 1 unit

Thank You



[www.zebronics.com](http://www.zebronics.com)