



HIGHKEY 685

USER MANUAL



www.dawgflex.com

Yo daWg....

Thank you for choosing the **HIGHKEY 685** Wireless Mechanical Keyboard . Please read the user manual carefully before operation and save this user manual for further reference.

Note:

- Avoid self-disassembly of keyboard, kindly approach our service team with reference to the following link for service support:
<https://dawgflex.com/pages/warranty-policy>
- Use the Type C cable provided inside the package for charging.


FEATURES

- daWg Glacier Switches
- Dual Style (Floating and Classic)
- Tri-Color swappable magnetic panel
- Pre-Lubed Switches
- 100% Keyboard
- 1000Hz Polling Rate
- Dynamic RGB Backlit
- Advanced Customization Software
- 1.8m RED Braided Detachable Cable
- Double Shot PBT Keycaps


TECH FLEX

Model	: HighKEY 685
Product Type	: Mechanical Keyboard
Connectivity	: Wired
Compatibility	: Windows/Mac
Number of Keys	: 104 Keys
Switch Type	: Glacier Switches
Switch color	: Blue
Polling Rate	: 1000Hz
Backlight	: RGB (Customizable)
Keycap Type	: Double shot PBT Keycaps
Cable length + Type	: 1.8m RED Braided Cable (USB A to USB C)
Multimedia Keys + Numbers	: 12 Keys (Integrated)
Software Support	: YES
Product Dimension	: 44 x 13.2 x 4 cm (W x D x H)
Net weight	: 1kg

INSIDE THE BOX




Keyboard x 1U



USB A to USB C cable
x 1U



QR code Guide
x 1U



Magnetic Panel
x 3U

INSTRUCTIONS FOR USE

WIRED MODE

Connect the Given USB A to Type-C cable from the PC/Laptop to the keyboard.

MULTIMEDIA KEY FOR WINDOWS

FUNCTION KEYS	MULTIMEDIA KEYS
F1	Brightness Decrease
F2	Brightness Increase

FUNCTION KEYS	MULTIMEDIA KEYS
F3	Task View
F4	Calculator
F5	Previous Track
F6	Play Pause
F7	Next Track
F8	Snipping Tool
F9	Volume Decrease
F10	Mute
F11	Volume Increase
F12	User Lock
Fn + Esc	Function Lock
Fn + Win	Windows Key Lock

LED FUNCTIONS

- Fn + Ins : To select desired color spectrum of the Keyboard
- Fn + Del : To select between the RGB modes

Fn + Home : To Increase the Speed of RGB by 4 Levels

Fn + End : To Decrease the Speed of RGB by 4 Levels

Fn + PgUp : To Increase the Brightness of the Keys by 4 Levels.

Fn + PgDn : To Decrease the Brightness of the Keys by 4 Levels.

Note: The THREE LED indicators flash simultaneously thrice to indicate when the max and min limit values are reached.

SOFTWARE FEATURES

Connection

To access the advanced Windows software, ensure your keyboard is connected to your Windows PC directly with USB cable.

Key Remapping & Macros

Use the Windows application to remap any key and configure macro function or secondary functions-perfectly optimized for gaming, productivity, or both.

Per-Key RGB Lighting

Take full control over lighting with an intuitive RGB editor, customize individual keys, set up color zones, dynamic animations, and reactive effects to match your style.

Profile Management

Effortlessly save distinct configurations whether gaming, work, or media as separate profiles, then


switch between them instantly via the software for optimized performance at the touch of a button.

HighKEY 685 software Installation:

Download and install the HighKey 685 software from the link below to unlock the full suite of settings and features for your keyboard.

Scan the QR to download the software.

Now open the software and you can notice the software interface as shown.



You can customize key functions and assign new actions to any keys. Once you're done configuring, be sure to save your changes. Then, create and name multiple profiles each tailored with its own set of key functions for easy switching whenever your workflow or activity changes.


LED Mode

This mode enables full control over the keyboard's backlight—select from a variety of colors and fine-tune your lighting to match your preferences.



Marco Function

Macro Function allows you to combine a sequence of keystrokes into a single key press, so one key can execute a custom key combination.




Macro edit panel


Using the Macro Function

1. Click the "+" button to start creating a macro.
2. Hit the Record button and type the desired sequence.

3. Once finished, click Stop and it will AutoSave itself.




4. After saving the macro functions go to Button Settings and choose the Key and select the Macro Function from the Dropdown Box.



5. After selecting Macro Function, Click on Save Button to assign the macro functions to the chosen Key.


This ensures your custom key sequences are properly recorded, assigned, and ready to use



whenever you switch profiles.

Software Setting

The Settings menu offers a range of options including Quick Keyboard Setup, USB Report Rate, Exchange Keys and more.



**STAY BOLD
STAY BOSS**

Let's Flex