



HIGHKEY 718



USER MANUAL

www.dawgflex.com

Yo daWg....

Thank you for choosing the **HIGHKEY 718** Wireless Mechanical Keyboard . Please read the user manual carefully before operation and save this user manual for further reference.

Note:

- Avoid self-disassembly of keyboard, kindly approach our service team with reference to the following link for service support:

<https://dawgflex.com/pages/warranty-policy>

- Kindly charge the keyboard before usage. The RED LED indicates the charging of keyboard. Once fully charged, the LED indication turns OFF. We suggest to use 5V DC adapter for charging.
- Use the Type C cable provided inside the package for wired mode usage.

FEATURES

- daWg Glacier Switches
- Gasket Structure
- 75% Keyboard
- 1000Hz Polling Rate
- 60 Days Backup*
- Hot Swappable
- Pre-Lubed Switches

- Effortless Tri-Modal Connection
- Seamless Multi-Device Switching
- Illuminating Metal Volume Knob
- Advanced Customization Software
- Dynamic RGB backlit
- 1.8m RED Braided Cable
- 4000mAh Battery
- Double Shot PBT Keycaps


* Basis 5H/ Day

TECH FLEX


Model	: HighKEY 718
Product Type	: Mechanical Keyboard
Connectivity	: Wired / 2.4GHz Wireless / 3 x Bluetooth
Connected devices	: Upto 5 Devices
Compatibility	: Mac / Windows / Android / iOS
Number of Keys	: 82 Keys
Switch Type	: Glacier Switches
Switch color	: Blue
Polling Rate	: 1000Hz (2.4GHz Wireless & Wired)
Hot Swappable	: Yes
Volume Control Knob	: Yes
Backlight	: RGB (Customizable)
Operating Range (M)	: >10 Meters

Keycap Type	: Double shot PBT Keycaps
Cable	: 1.8m RED Braided Cable (USB A to USB C)
Charging Time	: 5H
Backup Time	: 60 Days*
Multimedia Keys + Numbers	: 12 Keys (Integrated)
Software Support	: YES
Product Dimension (W x D x H)	: 33 x 14 x 3.5 cm
Net weight	: 800g


INSIDE THE BOX



Keyboard x 1U




Puller x 1U



Charging cable
x 1U



QR code Guide
x 1U



Extra switches
x 4U

INSTRUCTIONS FOR USE

Wired mode

- Connect the Given USB A to Type-C cable from the PC/Laptop to the keyboard.
- In the Top right Corner of the keyboard, slide the Toggle Switch to Wired mode



Wireless Modes


- In the Topright Corner of the keyboard slide the Toggle Switch to Wireless mode




Wireless Mode	Binding Keys	Activation Instructions
BT 1	Fn + 1	Long Press for 3 Sec to Pair with BT Device 1
BT 2	Fn + 2	Long Press for 3 Sec to Pair with BT Device 2
BT 3	Fn + 3	Long Press for 3 Sec to Pair with BT Device 3
2.4 Ghz RF	Fn + 4	-

Note

press the respective bindings to switch between 2.4GHz RF & paired BT devices.



LED Functions



Reset Procedure


- To Reset the entire Keyboard to Default mode Press & Hold the Fn + Space.

Battery Indicator

- While charging the keyboard the LED indicator will glow RED colour. When the Keyboard is fully charged the LED will go off .

MULTIMEDIA KEY FOR WINDOWS

Windows Mode



 +   Default Browser	 +   Snip
 +   Windows Explorer	 +   Calculator
 +   Previous Track	 +   User Lock
 +   Play/Pause	 +   Windows Lock
 +   Next Track	 +   Function Lock

MULTIMEDIA KEY FOR MAC

MAC Mode

 +  Press to activate MAC Mode

  Brightness Decrease	  Previous Track
  Brightness Increase	  Play/Pause
  Mission Control	  Next Track
  Spotlight Search	  Snip
  Siri Hold F5 (5 Sec)	 No Function
  Launch Pad	  User Lock

Note

On macOS in Bluetooth mode, to use the F-keys (F1–F12) as standard function keys:

- Open System Settings → Keyboard → Keyboard Shortcuts → Function Keys.
- Enable “Use F1, F2, etc. as standard function keys”.

SOFTWARE FEATURES

Connection

To access the advanced Windows software, ensure your keyboard is connected to your Windows PC—either wirelessly via the RF USB receiver or directly with a USB cable.

Key Remapping & Macros

Use the Windows application to remap any key and configure macro function or secondary functions—perfectly optimized for gaming, productivity, or both.

Per-Key RGB Lighting

Take full control over lighting with an intuitive RGB editor, customize individual keys, set up color zones, dynamic animations, and reactive effects to match your style.

Profile Management


Effortlessly save distinct configurations—whether gaming, work, or media—as separate profiles, then switch between them instantly via the software for optimized performance at the touch of a button.

HighKEY 718 software Installation:

Download and install the HighKey 718 software from the link below to unlock the full suite of settings and features for your keyboard.

Scan the QR to download the software.


Now open the software and you can notice the software interface as shown.



You can **customize key functions** and **assign new actions** to any keys. Once you're done configuring, be sure to **save your changes**. Then, create and name **multiple profiles**—each tailored with its own set of key functions—for easy switching whenever your workflow or activity changes.


LED Mode

This mode enables full control over the keyboard's backlight—select from a variety of colors and fine-tune your lighting to match your preferences.




LED Music for Keyboard

This feature delivers an immersive, audio-synced lighting experience—whether you're listening to music or deep into gameplay. The keyboard's LEDs dynamically pulse, flash, and shift colors in harmony with sound effects and beats, creating a truly rhythmic visual ambiance.



Marco Function


Macro Function allows you to combine a sequence of keystrokes into a single key press, so one key can execute a custom key combination.




Macro edit panel

Using the Macro Function

1. Click the New button to start creating a macro.
2. Hit the Record button and type the desired sequence.
3. Once finished, click Stop, then Save your macro.



4. Open the Profiles section and assign your macro to a key.
5. In the software, select the Macro tab, load the macro from the saved list, then click Save again.



This ensures your custom key sequences are properly recorded, assigned, and ready to use whenever you switch profiles.

Software setting

The Settings menu offers a range of options including Factory Reset, Language Selection, Sleep Timer, and more.

