

 ZEBRONICS

Hair Dryer

ZEB **HD201**



User Manual

www.zebronics.com

Dear Customer,
Please refer to the user manual of **ZEB-HD201**
Zebronics Hair Dryer for using the
product optimally.

Warning:

- Do not use this appliance with wet hands
- When the appliance is used in places with close proximity to water like in a bathroom, unplug it after use
- Always unplug the appliance after use.
- If the appliance overheats, it switches off automatically. Unplug the appliance and let it cool down for a few minutes.
- If the mains cord is damaged, Please take it to the authorized Zebronics Service centers only.

<https://zebronics.com/pages/warranty-policy>

Features:

- 2000W Powerful Hairdryer
- Sturdy Handle With Foldable Design
- Dedicated Cool Shot Button
- Powerful motor for better air flow
- 2 Air flow speeds
- 3 levels of heating
- Thermal Protection built-in

Specifications:

Input Voltage AC : AC 220/240V

Operating Wattage : 2000W

Heating Level : 3

Air flow Level	: 2
Attachments	: Airflow concentrator
Power cord length	: 1.8 meter
Product dimension (W x D x H)	: 20.8 x 7.7 x 21 cm
Net Weight	: 489 g
Country of origin	: PRC

Package Content

Hairdryer	: 1U
Airflow Concentrator	: 1U
QR Code Guide	: 1U

Product Description



Usage Instructions

To use the product safely and effectively, follow these step-by-step instructions:

1. Preparation of Hair:

- Wash your hair and gently towel-dry to remove excess water.
- Let your hair air-dry until it is at least 60% dry to minimize heat damage.
- Apply a heat protectant spray or serum to reduce the risk of hair damage.

2. Setting up the Hair Dryer:

- Plug the hair dryer into a power supply with AC 220 to 240V.
- Attach the nozzles or airflow concentrator to the hair dryer.

3. Operation:

- Switch on the hair dryer slider switch.
- Select the appropriate heat/ speed settings:
- For gentle drying or fine hair, use level 1.
- For thick or damp hair, use level 2.
- Keep the dryer at least 6 inches (15 cm) from your hair and scalp. Constantly move the dryer to avoid focusing heat on one area for too long.

4. Cool Shot:

- For setting up the air after the styling, a blast of cold air will be much helpful - so use the dedicated cool shot button at either speed levels to enable the hairdryer to provide a stream of air that is nearly equivalent to the room temperature.

5. After Use:

- Turn off the hair dryer and unplug it from the power supply.
- Allow it to cool down completely before storing.
- Clean any attachments and the air filter regularly to ensure longevity and performance.

Note:

- Avoid using high heat on soaking wet hair, and never block the air openings.
- Keep hair and hands away from the air inlet and outlet.

