



Power Bank
EnergiPod PB17



User Manual

www.zebronics.com

Thank you for purchasing **ZEB-Energipod PB17** Power bank. Please read this user manual carefully before operation & save this user manual for future reference.

Note:

- Avoid the use of this product at the high-temperature and high humidity environment.
- Avoid self-disassembling of product, as it will result in the failure of warranty.
- Please charge the product with a power adapter output rated DC 5V/2A.

Caution :

May explode if disposed off in fire.

Features :

Dual Output

LED Indicator

Mobile / Tablet Compatible

Type C & Micro USB Input

Over charge protection

Overload protection

Short circuit protection

Specifications :

Battery capacity : 10000mAh

Input : DC 5V/2A

Output 1 : DC 5V/2.4A

Output 2 : DC 5V/2.4A


(Total 2.4A Max.)

No. of Output port : 2
Charging time : 5 - 6h
Product dimension : 6.9 x 1.6 x 13.6 cm
(W x D x H)
Net. weight : 227g

Package contents :


Power bank : 1 U
Charging cable : 1 U
QR Code Guide : 1 U

Charging the Power Bank :



- Connect the Type C/micro USB end of the charging cable to the power bank and the USB end to the charger / adapter with a DC 5V output.

Charging your Device with the Power Bank:



- Connect the Type C/micro USB end of the charging cable to the device and the USB end to the output ports of power bank.
- You may connect two different devices at the same time in order to charge them simultaneously.

ISO 9001:2015 Certified Company
www.zebronics.com