



Power bank
MW52



User Manual

www.zebronics.com

Thank you for purchasing **ZEB-MW52** power bank. Please read this user manual carefully before operation & save this user manual for future reference.

Note:

- Avoid the use of this product in high-temperature and high-humidity environments.
- Please charge the product with a power adapter output rated Type-C (DC 5V/3A, 9V/2A, 12V/1.5A) and Micro USB (DC 5V/2A, 9V/2A, 12V/1.5A).
- Avoid the self-disassembling of the product, as it will result in the failure of the warranty.
- To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Features

Dual USB Output

Fast Charge

LED Indicator

Mobile/Tablet Compatible

Type C Input & Output

Micro USB Input

Over Charge Protection

Overload Protection

Short Circuit Protection


Specifications

Battery Capacity	: 20000mAh
TYPE C Input	: DC 5V/3A, 9V/2A, 12V/1.5A
Micro USB Input	: DC 5V/2A, 9V/2A, 12V/1.5A
Output 1	: DC 5V/3A, 9V/2A, 10V/2.25A, 12V/1.5A
Output 2	: DC 5V/3A, 9V/2A, 10V/2.25A, 12V/1.5A
Output 3 (TYPE C)	: DC 5V/3A, 9V/2.22A, 12V/1.67A (22.5W max. output)
No.of Output port	: 2 USB + 1 Type C PD
Product Dimension (W x D x H)	: 6.8 x 13.6 x 2.8 cm
Net Weight	: 397g

Package contents :

Power bank	:1 U
Charging cable	:1 U
QR Code guide	:1 U


Charging the Power Bank:



- The USB end to the charger or adapter with a Type C (DC 5V/3A, 9V/2A, 12V/1.5A) or micro USB (DC 5V/2A, 9V/2A, 12V/1.5A).

Note : All the four LED on the power bank will glow constantly once the power bank is fully charged

Charging your Device with the Power Bank:



- Connect the Type C/micro USB end of the charging cable to the device and the USB/Type C end to the output ports of the power bank.

