ZEBRONICS

ZEB Power Bank **MW56**

User Manual

Thank you for purchasing the **ZEB-MW56** power bank. Please read this user manual carefully before operation and save it for future reference.

Note:

• Avoid the use of this product in high-temperature and high-humidity environments.

• Please charge the product with a power adapter output rated Type-C (DC 5V/3A, DC 9V/2A, DC 12V/1.5A).

• Avoid the self-disassembling of the product, as it will result in the failure of the warranty.

• To know more about Terms and conditions for warranty policy, please visit https://zebronics.com/pages/warranty-policy

Caution:

There is a risk of explosion if the product is disposed of in the fire.

Features:

Dual USB Output
Fast Charge
Transparent Body
LED Digital Display
Mobile/Tablet Compatible
Type C Input & Output
Over Charge Protection
Overload Protection
Short Circuit Protection

Specifications :

|	
Battery capacity	: 10000mAh
TYPE C Inputs	: DC 5V/3A, 9V/2A, 12V/1.5A
Output 1	: DC 5V/4.5A, 9V/2A, 12V/1.5A
Output 2	: DC 5V/4.5A, 9V/2A, 12V/1.5A
Output 3 (TYPE C)	: DC 5V/3A, 9V/2.22A, 12V/1.67A (Total 22.5W Max.)
No.of Output ports	: 2 USB + 1 Type C PD
Charging time	: 4.5h
Product dimensions (WxDxH)	: 6.7 x 14.6 x 1.6 cm
Net. weight	: 238g

Package contents :

Power bank	: 1 U
Charging cable	: 1 U
QR Code guide	: 1 U

Charging the Power Bank :

USB Charger / Adapter   Type-C   Power Bank

Connect the Type C end of the charging cable to the power bank and the USB end to the charger or adapter with a Type C (DC 5V/3A, DC 9V/2A, DC 12V/1.5A) cable.

Charging your device with the Power Bank:

| Output port | Device with |
| USB x 2 / Type-C | Type-C / Micro USB Lightning Support |

Connect the Type C/micro USB end of the charging cable to the device and the USB/Type C end to the output ports of the power bank.