



ZEBRONICS
ALWAYS AHEAD

LED Projector

 **Pixa**
Play **21**



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing the **ZEB-Pixaplay 21 LED projector**. Please read the user manual carefully before usage and save it for future reference.

Note :

- *To provide a stable power supply, kindly use the cable provided with the product and connect to a AC 100-240V, 50/60Hz power source.*
- *Avoid the self-disassembly of the product as it results in voiding the product's warranty.*
- *Avoid looking directly at the projector lens while it is active.*
- *Make sure that the projector's air vents are not blocked while in use. The device must be kept in a well ventilated surrounding for proper functioning.*
- *It is recommended to turn OFF the projector after a continuous usage of maximum 6 hours.*
- *Place the projector away from water or other liquids. Avoid water accumulation and ensure good ventilation.*
- *In case of enquiry regarding the projector, email us at enquiry@zebronics.com or contact us at 044 4000 0004.*
- *To know more about Terms and conditions for warranty policy, please visit*
<https://zebronics.com/pages/warranty-policy>

Features:

Home Theatre Projectors for Movies, TV & Gaming etc.

Projector comes with HDMI, VGA ,AV IN, AUX OUT, USB x 2

Built in Speaker

Wide Compatibility

Ceiling Mountable

Remote Control

Dolby Audio

Specification:

Screen size : 111 cm - 508 cm

Native Resolution : 1280 x 720P

Max. Supported Resolution : 1920 x 1080P (Max)

Display Technology : LED

Lifespan : 30,000H

Brightness : 3000 lumens

Contrast ratio : 1000:1

Projection Distance : 1.5m - 5.6m

Port Interface : HDMI, VGA ,AV IN, AUX OUT,USB x 2

Video file format : AVI, MP4, MPG, MPEG1, MPEG2, MKV, MOV, FLV, H.264

Input Voltage : AC 100-240V, 50/60Hz

Product Dimension : 24.5 x 16.6 x 8.15 cm
(W x D x H)

Net. weight : 1.31 kg

Package Contents:

Projector : 1 U

Remote Control : 1 U

Power Cord : 1 U




AV cable : 1 U

HDMI Cable : 1 U


QR Code Guide : 1 U

Cotton Swab Pack : 1 U

Product Description



Remote Control




***NOTE:**

- 1. To avoid power shortage, do not mix and use the old and new batteries.*
- 2. To avoid battery leakage corrosion, if the remote controller is not used for a long time, please take the battery out.*

Setting Up the Projector


Power cord setup:

Plug-in the power cord into the socket as described in the image below




Power on/Power off

Press power button on the projector or on the remote to switch the power On/Off.



Boot Up

After turning on, the projector boots up within a few seconds and displays the multimedia input screen.



Focus and Keystone correction

Keystone

If the projector displays the image that is wider in the top and narrow in the bottom or vice versa, then use the keystone adjuster to correct the image to have an even top and bottom edges.






Image focus

Use the focus adjuster (refer to the product image) to adjust the focus of the projector until the picture displayed on the screen is in good clarity.



Projector Connection



①



② ③



④



⑤



⑥




**Could connect multi-device and applications.*


Multi-Media Connection

Insert the USB into the respective ports,
(refer picture below)

Choose multimedia as signal source




Choose the content which you need to display



Movie, Music,
Picture,
Text.




Choose the file which you want to play and press the play/pause key to open the file and display the content.




AV Video Equipment Connect

Connect 3 in 1 RCA cable projector to AV slot (as shown in the image below) choose the signal source video.




HDMI Equipment Connect

HDMI of the projector can be connected to computer/ DVD player/ and all similar devices that can provide signal via HDMI port.



3.5mm Audio Device Connect

The audio output of the projector can be dedicatedly given to any speaker or headphone that supports the 3.5mm AUX mode connection.



Menu Guides

Remote control:

Press “ ≡ ” key, then the main menu will appear. Use navigation keys of the remote to access the following sub menus

Image Menu:

This menu lists the following sub menus like Picture mode (Standard, Soft, User, Dynamic), color temperature (cool, Medium, Warm, User), Aspect Ratio (Auto, 4:3, 16:9) Noise reduction (Default, Low, Middle, High, Off).

Audio Menu:

In this audio settings sub menu, you could set the balance (-50 to 50), Auto volume (Off/On) , Surround Sound (Off, SRS, Surround)


Time Menu:

In this submenu settings, You can set the clock, OFF time, ON time, Sleep time, Auto sleep.

Other settings menu:

This Menu provides lists projector's Color Range, OSD Duration, OSD Language, Factory Reset and Software Update menus

Projector distance & size



ISO 9001:2015 Certified Company

www.zebronics.com