



LED Projector

**PixaPlay<sup>®</sup> 21**



## User Manual

[www.zebronics.com](http://www.zebronics.com)

Dear Customer,

Thank you for purchasing the **ZEB-Pixaplay 21 LED Projector**. Please read the user manual carefully before usage & save it for future reference.

**Note :**

- *To provide a stable power supply, kindly use the cable provided with the product and connect to a AC 100-240V, 50/60Hz power source.*
- *Avoid the self-disassembly of the product as it results in the failure of Warranty.*
- *Avoid looking directly at the projector lens while it is active.*
- *Make sure that the projector's air vents are not blocked while in use. The device must be kept in a well insulated surrounding for proper functioning.*
- *It is recommended to power OFF the projector after a continuous usage of 6 hours.*
- *Place the projector away from water or other liquids. Avoid water accumulation and ensure good ventilation.*
- *In case of enquiry regarding the projector, email us at [enquiry@zebronics.com](mailto:enquiry@zebronics.com) or contact us at 044 4000 0004.*

**Features :**

Home Theatre Projectors for Movies, TV & Gaming etc.

Projector comes with HDMI, VGA, AV IN, AUX OUT, USB x2

Built in Speaker  
Wide Compatibility  
Ceiling Mountable  
Remote Control

**Specification:**




Screen size	: 111-508cm
Native Resolution	: 1280 x 720P
Max. Supported Resolution	: 1920 x 1080P (Max)
Display Technology	: LED
Lifespan	: 30,000H
Brightness	: 4400 lumens
Contrast ratio	: 1000:1
Projection Distance	: 1.5m - 5.6m
Port Interface	: HDMI, VGA, AV IN, AUX OUT, USB x 2
Video file format	: AVI, MP4, MPG, MPEG1, MPEG2, MKV, MOV, FLV, H.264
Input Voltage	: AC 100-240V, 50/60Hz
Product Dimension	: 24.5 x 16.6 x 8.15 cm (W x D x H)
Net. weight	: 1.31 kg


## **Package Contents:**

Projector	: 1 U
Remote Control	: 1 U
Power Cord	: 1 U
AV Cable	: 1 U
HDMI Cable	: 1 U
Cotton Swab Pack	: 1 U
QR Code Guide	: 1 U



## Product Description






**\*NOTE:**

1. To avoid power shortage, please do not mixed use the old and new battery.
2. To avoid battery leakage corrosion, if do not use remote control for a long time, please take the battery out.


# Setting Up the Projector


## Preparation before light on

As following picture, connect the power adaptor.




## Power on/Power off

Press  button on the projector or on the remote control to switch the power on/off.



## Boot screen



As the projector start working, after screen display 2 to 5 seconds of boot screen, then come into the multimedia screen.



## Focus & Keystone

### Keystone



If the projector displays the image that are wider in the top and narrow in the bottom or vice versa, then use the keystone adjuster to correct the image to have even top and bottom edges.




## Image focus

The focus of the projector can be adjusted by the following steps :

1. Place the projector on a flat surface.
2. Use the focus adjuster (refer product image) to adjust the focus of the projector until the picture displayed on the screen is in good clarity.



## Projector Connection



①




② ③



④



⑤




⑥




*\*Could connect multi-device and applications.*

## Multi-Media Connection


Insert the USB into the respective ports. (refer to picture below)





Choose multi-media signal source.



Choose the content which you need display : Movie, Music, Photo, Text.




Choose the file which you want to display and press  display or stop.



## AV Video Equipment Connect


Use 3 in 1 RCA cable and connect projector to AV slot (as shown in the image below) choose the signal source video.

Support Format : NTSC / PAL



## HDMI Equipment Connect


HDMI slot can be connected to computer and all the device with HDMI slot. As connected, select the source HDMI.





## 3.5mm Audio Device Connect

The audio output of the projector can be dedicatedly given to any speaker or headphone that supports the 3.5mm AUX mode connection.



## Menu Guides

### Remote Control

Press " ≡ " key, then the main menu will appear. Use navigation keys of the remote to access the following sub menus

### Image Menu

This menu lists the following sub menus like Picture mode (Standard, Soft, User, Dynamic), color temperature (cool, Medium, Warm, User), Aspect Ratio (Auto, 4:3, 16:9) Noise reduction (Default, Low, Middle, High, Off).

## Audio Menu :

In this audio settings sub menu, you could set the balance (-50 to 50), Auto volume (Off/On), Surround Sound (Off, SRS, Surround)


## Time Menu :

In this submenu settings, You can set the clock, OFF time, ON time, Sleep time, Auto sleep.

## Other Settings Menu :

This Menu provides lists projector's Color Range, OSD Duration, OSD Language, Factory Reset and Software Update menus

## Projector distance & size



ISO 9001:2015 Certified Company  
[www.zebronics.com](http://www.zebronics.com)