

PixaPlay® 35



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing the **ZEB-PIXAPLAY 35** Smart LED Projector. Please read the user manual carefully before usage& save it for future reference.

Note:

- To provide a stable power supply, kindly use the power adapter provided with the product.
- •Avoid the self-disassembly of the product as it results in the failure of Warranty.
- •Avoid looking directly at the projector lens while it is active.
- Make sure that the projector's air vents are not blocked while in use. The device must be kept in a well ventilated surrounding for proper functioning.
- It is recommended to power OFF the projector after a continuous usage of 6 hours.
- Place the projector away from water or other liquids. Avoid water accumulation and ensure good ventilation.
- In case of enquiry regarding the projector, email us at enquiry@zebronics.com or contact us at 044 4000004.

Features:

- Home Theater Projectors for Movies, TV & Gaming etc..
- 4K UHD (Support)
- Upto 254cm Screen Size
- 4000 Lumens
- Auto Keystone Adaptation *
- 30,000h Lifelong LED Lamp
- ◆ Multi Connectivity (BT v5.4 | HDMI | USB)
- Built in Speaker
- Dual band Connectivity (2.4GHz & 5GHz)
- Remote Control
- Quad Core Processor
- Miracast
- IOS Screen Mirroring
- Smart Projector
- APP Support

*For vertical adjustment only.

Specification:

Screen size : 101.6-254cm Native Resolution : 1280 x 720p

Max. Supported : 4K

Resolution

RAM : 1GB

Core Processor : Quad Core Processor

Storage (ROM) : 8 GB Android Version : 11.0

Wi-Fi Connectivity : WiFi 6 Dual Band

Connectivity (2.4GHz & 5GHz)

BT Version : v5.4

Lamp Lifespan : 30,000h

Brightness: 4000 Lumens

Contrast ratio : 1000:1 Projection Distance : 0.65 - 2m

Port Interface : 1 x HDMI, 1 x USB

Video file format : Full-format decoding

including HEVC/VP9/ AVS2/AVC 4K@30fps

and MPEG1/MPEG2/AV1 1080p/60fps decoding

and so on

Input Voltage 1 : DC 36V=0.95A Input Voltage 2 : DC 12V=0.7A

Product Dimension

 $(W \times D \times H)$: 8.8 x 10.5 x 16.5 cm

Net. weight :355 g

Package Contents:

Projector :1U


Remote Control :1 U Power Adapter :1 U


HDMI Cable :1 U

Cotton Swab Pack : 1 U


OR Code Guide :10

Product Description:






Remote Control




Setting Up the Projector:

- 1. Plug the Power cord into the projector's AC power input. Insert the other end of the power cord into a standard wall power socket. Ensure the wall socket is turned on to supply power.
- 2. Please place the projector on a flat surface to ensure proper projection. Now turn the projector On by pressing the power button either on the panel or on the remote.
- 3. The projector should be aligned straight to the screen *I* the place of projection .



Projection Distance and Size:

The recommended projector screen size is upto 254 cm. For an improved viewing experience, it is recommended to use the projector in a room that provided as much darkness as possible.



Note: The above mentioned image is for indicative purpose alone while in actual product, the distance to screen size may vary from the values mentioned above.

Focus Adjustment:



Use the focus knob to adjust the focus of the projector.

Note: Auto focus feature is not available, the product features only manual focus.

Keystone Adjustment:

The 4 point keystone can be adjusted in Display settings.

Android Home:

- 1. Once the projector is turned on, the projector will lead you to the home screen.
- 2. The home screen displays Apps, Settings, Source, Files.
- 3. Once the Up Arrow on the remote control is pressed the drop down box appears, which consists of Source, Settings and Files.



Settings:

Open the homepage, select settings from the drop down box appeared by pressing the Up arrow button on the remote control.

This settings houses the following submenus: Network settings, Bluetooth settings, projection settings, language Setting, date settings, application settings, system update, other settings.



USB Connection:

Plug the USB to the port present at the rear side of the projector. Now navigate to the source tab present in the homepage, then select USB sub-menu.




HDMI Connection:

Once the HDMI is connected to the projector, you will need to select the specific signal source as input. After connecting, the content played on the source will be streamed on the projector.



Bluetooth Settings:

- 1. Go to Settings > Bluetooth settings.
- 2. Turn the Bluetooth Connection On and search for nearby bluetooth devices.
- 3. Choose the desired bluetooth device to pair and connect.



Network Settings:

- 1. Go to Settings > Network settings.
- 2. WIFI setting, WIFI "ON",
- 3. Select the Desired network and input password to connect to the network



ISO 9001:2015 Certified Company www.zebronics.com