



AI Selfie Stick
ZEB **MOMENTS** 1000



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing the **"ZEB-MOMENTS 1000"** AI Selfie Stick. Please read this user manual carefully before operation and save it for further reference.

Safety Measures:

- *Please charge the remote and Selfie Stick with power adapter output rated voltage DC 5V.*
- *Kindly approach our service team with the reference to the following link for service support:*

<https://zebronics.com/pages/service-centres>

Features:

- 360° AI Face Tracking
- Smart Palm Gestures
- Slow Mo Rotation Mode
- 8 Section Aluminum Arm
- 270° Angle Adjustment
- Detachable BT Shutter Button
- Max 17.5 cm Screen Size
- Lightweight and Travel-Friendly
- Reinforced Quadpod
- Rubberized Phone Clamps
- Safe and Stable Hold

Specifications:

Supports Mobile : Max 17.5 cm Screen Size

Material : Aluminum Alloy + ABS

Product Dimension (W x D x H)

Folded Dimension : 4 x 8.9 x 35 cm

Expanded Dimension : 45.5 x 45.5 x 184 cm

Net Weight : 518g

Package Contents :

Selfie Stick : 1 U

Charging Cable : 1 U


QR Code Guide : 1 U

Product Description:



1. Detachable BT Shutter Remote
2. Rocker Handle
3. Type-C Port
4. AI Smart Camera
5. Status Indicator
6. Power ON/OFF Button
7. Rotation Lock
 - Toggle Up to release the Lock
 - Toggle Down to Lock the Rotation

Detachable BT Shutter Button:



Instructions for Use:

Connectivity Procedure:

- Long Press the Power Button to turn ON the Remote and Green LED will start blinking.
- Turn ON BT on your phone and search for the nearby BT compatible devices.
- Search for the BT name **“ZEB-Moments 1000”** and tap to connect it.
- Once connected the LED will go OFF.
- Long Press the Power button to Power OFF the remote.

Camera Button:

- In Camera Mode, Press the button once to click a picture.
- The Green LED blinks whenever a picture is clicked.

Slow Mo Rotation Mode:

- To enable Slow Mo Rotation Mode, Triple press the Power Button on the Rocker Handle.
- Make sure the Rotation Lock is toggled up to release the Rotation Lock. To Lock the rotation, toggle down the Rotation Lock.
- Triple press again to turn off the Slow Mo Rotation Mode.

Charging Instruction:

- Please charge the remote and Selfie Stick with power adapter output rated voltage DC 5V via Type-C Port.
- The Red LED will be glowing while charging and it goes OFF when the device is fully charged.