



Selfie Stick
ZEB **MOMENTS** 400



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing the **"ZEB-MOMENTS 400"** Selfie Stick. Please read this user manual carefully before operation and save it for further reference.

Safety Measures:

- *Please charge the remote and light with power adapter output rated voltage DC 5V.*
- *Kindly approach our service team with the reference to the following link for service support:*

<https://zebronics.com/pages/service-centres>

Features:

- 9 Stage Stainless steel Arm
- Dual Detachable LED Ring Lights
- 360° Rotation
- 3 Light Modes
- LED Brightness Adjustment
- Adjustable 180° Lights
- Detachable BT Shutter Button
- Max 17.5 cm Screen Size
- Lightweight and Travel-Friendly
- Safe and Stable Hold
- Rubberized Phone Clamps

Specifications:

Supports Mobile : Max 17.5 cm Screen Size

Material : Stainless steel + ABS

Product Dimension (W x D x H)

Folded Dimension : 3.3 x 5.5 x 30 cm

Expanded Dimension : 35.5 x 30.5 x 181.5 cm

Net Weight : 365 g

Package Contents :

Selfie Stick : 1 U


Ring Lights : 2 U

Charging Cable : 1 U

QR Code Guide : 1 U


Button & Port Description:

Remote



1. Power Button
2. LED Indicator
3. Camera Button
4. Type-C Port

Light:



Instructions for Use:

Connectivity Procedure:

- Long press the power button to Power ON/OFF the remote, and you will see the LED Indicator will start blinking.
- Turn ON BT on your phone and search for the nearby BT compatible devices.
- Search for the BT name **“ZEB-Moments 400”** and tap to connect it.
- Once connected the LED Indicator will go off.

Camera Button:

- In camera mode, press the button once to click a picture.
- In video mode, press the button once to start recording and press again to stop recording.
- The LED Indicator appears whenever the camera button is pressed.

Ring Light:

- Press the power button on the rear side of the light to turn it ON.
- Press the power button once to switch between light modes (Cool, Warm, Natural).
- In each of the light mode, press the power button for 2s to adjust between 3 brightness levels.

- The lights can be rotated 360° and folded 180° individually.

Charging Instruction:

- Please charge the remote and the lights with power adapter output rated voltage DC 5V via Type-C Port.
- Red LED Indicator will be glowing while charging and it goes off when the device is fully charged.