



Selfie Stick
ZEB **MOMENTS** 700



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing the **"ZEB-MOMENTS 700"** Selfie Stick. Please read this user manual carefully before operation and save it for further reference.

Safety Measures:

- *Please charge the remote and light with power adapter output rated voltage DC 5V.*
- *Kindly approach our service team with the reference to the following link for service support:*

<https://zebronics.com/pages/service-centres>

Features:

- 8 Section Aluminum Arm
- Square LED Fill Light
- 3 Light Modes
- LED Brightness Adjustment
- 360° Rotation
- 180° Foldable
- Reinforced Quadpod
- Detachable BT Shutter Button
- Max 17.5 cm Screen Size
- Lightweight and Travel-Friendly
- Safe and Stable Hold
- Rubberized Phone Clamps

Specifications:


Supports Mobile : Max 17.5 cm Screen Size
Material : Aluminum Alloy + ABS
Product Dimension (W x D x H)
Folded Dimension : 15.7 x 8.3 x 29.5 cm
Expanded Dimension : 46.5 x 46.5 x 188 cm
Net Weight : 580g

Package Contents :

Selfie Stick : 1 U
Charging Cable : 1 U
QR Code Guide : 1 U


Button & Port Description:

Remote:



1. Power Glide Switch
2. LED Indicator
3. Camera Button
4. Type-C Port

Light:



Instructions for Use:

Connectivity Procedure:

- Slide the Power Button upwards to Power ON the remote, and you will see the LED Indicator will start blinking.
- Turn ON BT on your phone and search for the nearby BT compatible devices.
- Search for the BT name "**ZEB-Moments 700**" and tap to connect it.
- Once connected the LED Indicator will go OFF.
- Slide the Power Button downwards to Power OFF the remote.

Camera Button:

- In Camera Mode, Press the button once to click a picture.
- In Video Mode, Press the button once to start recording and press again to stop recording.
- The LED glows whenever the camera button is pressed.

Fill Light:

- Press the Multi-Function Button (**MFB**) on the side of the light to turn it ON.
- Press the **MFB** once to switch between light modes (Cool, Warm, Natural) and to adjust between 3 brightness levels of each light mode.

Charging Instruction:

- Please charge the remote and the light with power adapter output rated voltage DC 5V via Type-C Port.
- Red LED will be glowing while charging and it goes OFF when the device is fully charged.

