

 ZEBRONICS

Trimmer

ZEB **HT120**



**UNLEASH  
THE  
BOLD**

**User Manual**

[www.zebronics.com](http://www.zebronics.com)

## **Dear Customer,**

Thank you for purchasing the **ZEB-HT120 Trimmer**. Please read the user manual carefully before usage & save it for future reference.

### **Note:**

- *Use this product only for its intended use.*
- *Do not dismantle the trimmer in order to avoid electrical shock & other accidents and this may lead to devoid of warranty.*
- *Keep the product and cords away from high temperature and high humidity places.*
- *Avoid using and charging the product with wet hands.*
- *Do not throw the product into fire.*

### **Features:**

- Upto 150 mins Cordless use
- Corded & Cordless usage
- 3 Guides combs (1-3mm)
- Washable Attachments
- Skin friendly
- Rounded tip blade
- Stainless Steelblades
- LED Display
- Easy to hold design
- Type-C Charging
- Built in Rechargeable battery


### **Specifications:**



|                                  |                          |
|----------------------------------|--------------------------|
| Input Voltage                    | : DC 5V 1A               |
| Usage type                       | : Corded & Cordless      |
| Trimmer Body Material            | : ABS Plastic            |
| Trimming Range                   | : 0.5mm - 3mm            |
| No of Clips Attachments          | : 3nos.(1mm , 2mm & 3mm) |
| Blade material                   | : Stainless Steel        |
| Charging time                    | : Upto 120mins           |
| Run time                         | : Upto 150mins           |
| Power consumption                | : 5W                     |
| Product Dimension<br>(W x D x H) | : 15.1 x 4.3 x 3.2 cm    |
| Net Weight                       | : 129g                   |

### **Package Content:**

|                                    |       |
|------------------------------------|-------|
| Trimmer                            | : 1 U |
| Charging cable                     | : 1 U |
| Charging Brush                     | : 1 U |
| Blade Safety Cap                   | : 1 U |
| 3 Guides combs<br>(1mm ,2mm & 3mm) | : 3 U |
| Oil                                | : 1 U |
| QR Code Guide                      | : 1 U |

## Product Representation :










1. Trimmer Head
2. Finger Grip
3. Power On/Off
4. LED Display
5. Guide Combs
6. Blade Safety Cap
7. Cleaning Brush
8. Charging Cable
9. Oil

## Usage Instructions:

1. Fully charge the trimmer before every usage for better performance.
2. Add or remove the guide combs as per the levels of trimming needed.
3. Press the power button to switch the trimmer On/Off.



## Cleaning the Trimmer after Usage:

1. Use the brush to remove the hairs from the blades of the trimmer head.
2. Also, clean the head socket of the base with the brush to clean the hair particles.
3. Avoid the usage of the water or other cleaning liquid / solvents for cleaning the trimmer.

## **Charging Instruction:**

The trimmer can be charged with the charging cable that comes with the product. Connect the USB connector of the charging cable to the USB port of a DC5V charger and the other end to the trimmer. The LED display shows the battery percentage.

