

 ZEBRONICS

Trimmer

ZEB **HT201**



User Manual

www.zebronics.com

Thank you for purchasing **ZEB-HT201** Trimmer. Please read the user manual carefully before usage & save it for future reference.

Note:

- ◆ Use this product only for its intended use.
- ◆ Do not dismantle the trimmer in order to avoid electrical shock & other accidents and this may lead to devoid of warranty.
- ◆ Keep the product and cords away from high temperature and high humidity places.
- ◆ Avoid using and charging the product with wet hands.
- ◆ Do not throw the product into fire.


Features:

- ◆ Upto 180mins Cordless use
- ◆ Rounded tip blade
- ◆ Self Sharpening Stainless steel blades
- ◆ 3+1 Guide combs
(1.5, 3, 4.5mm and blade cover)
- ◆ Ergonomic design
- ◆ 120mins USB Charge

Specification :

Input Voltage	: DC 5V
Usage Type	: Corded & Cordless
Trimmer	
Body Material	: ABS
Trimming Range	: 0.5mm - 4.5mm
No of Clips	
Attachments	: 4nos (1.5mm, 3mm, 4.5mm, Blade cover)
Blade Material	: Stainless steel
Charging Time	: Upto 120mins
Run Time	: Upto 180mins
Power Consumption	: 5W
Product Dimension (W x D x H)	: 4 x 3 x 15.4 in cm
Net Weight	: 167g

Product Description :



1. Trimmer Head

2. Power Button

3. LED Indicator

4. Charging Port


5. Cleaning Brush

6. Guide Combs + Blade Cover



7. Charging Cable

Usage Instructions:

1. Fully charge the trimmer before every usage for better performance.
2. Please Add or remove the guide combs as per the levels of trimming needed.
3. Press the power button to switch the trimmer On/Off.





Attaching The Clips



Removing The Clips

Cleaning the Trimmer After Usage:

1. Use the brush to clean the hair from the trimmer head.
2. Avoid the usage of water and other cleaning liquid or solvents for cleaning the trimmer.



Charging Instruction:

The trimmer can be charged with the charging cable that is provided with the product. Connect the USB connector of the charging cable to the USB port of the DC5V charging adapter and the type-C end of the charging cable should be connected to the type-C charging port of the trimmer. The LED indicator blinking indicated the charging of the product. Upon full charge, the LED indicator glows constantly.

