



3 in 1 Wireless Charger

**ZEB** **MAGBOOST** 500



## User Manual

[www.zebronics.com](http://www.zebronics.com)

## **Dear Customer,**

Thank you for purchasing the **"ZEB-MAGBOOST 500"** 3 in 1 Wireless Magnetic Charging Pad. Please read this user manual carefully before operation and save it for further reference.

### **Note:**

- Avoid the usage of this product at high-temperature and high-humidity environments.
- Avoid the self-disassembling of the product or it will result in voiding the Product's warranty.

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

### **Features:**

- MagSafe Compatible\*
- 23W (Max.)
- 3 in 1 simultaneous usage
- In-built Clock Function with Alarm
- Matte Finish
- Rapid charge
- 1m Cable
- Foreign Object Detection
- For Smartphones / Earbuds / Smartwatches
- Built in protections
- LED indicators

\*Recommended for compatible iPhone and Apple watch series

### **Specifications:**

|                        |                        |
|------------------------|------------------------|
| Input Interface        | : Type-C               |
| Input                  | : 5V/2A, 9V/3A         |
| Output 1 (Smartphone)  | : 15W                  |
| Output 2 (TWS)         | : 5W                   |
| Output 3 (Smart Watch) | : 2.5W                 |
| Charging Distance      | : 2-6mm                |
| Product Dimension      |                        |
| (W x D x H)            | : 17.5 x 9.1 x 13.7 cm |
| Net Weight             | : 230 g                |

### **Package Contents :**

|               |      |
|---------------|------|
| Charging pad  | : 1U |
| Cable         | : 1U |
| QR Code Guide | : 1U |

## Product Description :



- 1.Clock Display
- 2.Mobile Charging Pad
- 3.TWS Charging Pad
- 4.Smartwatch Charging Pad
- 5.Type-C Charging Port
- 6.Clock & Alarm Buttons
- 7.LED Indicator



## Clock Function:



## Buttons Functions

### Power Button:

Single press to turn the display ON or OFF.

### Format / Time Changing button

#### Change Time Format

- Single Press to switch between 12-hour and 24-hour time formats.

## Set Time & Calendar

1. Press and hold the button for 2 seconds to enter the setting mode.
2. Then single Press the button to select:
  - Hour
  - Minute
  - Month
  - Day
3. Press the increase or decrease button to adjust the selected value.
4. The setting is saved automatically after a few seconds of no operation.

## Alarm

- This clock supports two alarm modes:
  - Alarm 1 (L1): Press and hold the increase button to enter Alarm 1 (L1) settings.
  - Alarm 2 (L2): Press and hold the Decrease button to enter Alarm 2 (L2) settings.
- When the alarm rings, press any key to stop it.

## Increase Button / Alarm 1 Button

### Set Alarm1

1. Press and hold the increase button to enter Alarm 1 (L1) setting mode.
2. The upper-right two digits will flash.
3. Then Single Press the increase button to turn the alarm ON or OFF.
4. Single Press the Time change button to switch between Hour and Minute.
5. Press the Increase or decrease button to adjust the selected value
6. The alarm setting is saved automatically.
7. When the alarm is ON, the alarm indicator lights up.  
When it is OFF, the indicator turns off.



## Decrease Button / Alarm 2 Button

### Set Alarm 2

1. Press and hold the Decrease button to enter Alarm 2 (L2) setting mode.
2. The upper-right two digits will flash.
3. Then Single Press the decrease button to turn the alarm ON or OFF.
4. Single Press the Time change button to switch between Hour and Minute.
5. Press the Increase or decrease button to adjust the selected value.
6. The alarm setting is saved automatically.
7. When the alarm is ON, the alarm indicator lights up. When it is OFF, the indicator turns off.




### Auto Exit

- If no button is pressed for 5 seconds, the device automatically exits the setting mode and returns to the normal display.

## Instruction to Use:

- Connect the charger to a 25W adaptor with the provided cable.



- Place device (Smartphone / Smart watch / TWS) on Top of their Respective Charging pad. (As shown below)



### **LED Indicator:**

- **Smartphone Charging Pad:** The smartphone is currently charging, as indicated by a glowing Red LED.
- **TWS Charging Pad:** The TWS is currently charging, as indicated by a glowing Red LED.
- **Foreign Object Detection (FOD):** A red LED Indicator flashes rapidly.

### **Note:**

- *Please make sure if your device (Smartphone / Smart Watch /TWS) has the wireless charging function.*
- *The MagSafe function will be compatible only with the supported Iphone &Apple watch series.*

