



ZEBRONICS  
ALWAYS AHEAD

Wireless Headphone  
**ZEB BANG PRO**



User Manual

[www.zebronics.com](http://www.zebronics.com)

## **Dear Customer,**

Thank you for purchasing the **ZEB-BANG PRO** Wireless Headphone. Please read the user manual carefully before usage & save it for future reference.

### **Note:**

- Avoid the usage of this product at the high temperature and high humidity environment.
- Avoid the self-disassembly of the product as it results in the failure of Warranty.
- Please charge the product with a power adapter rated DC 5V (Output).

### **Caution:**

Listening at high volume can cause hearing impairment. Please limit your usage time at high volume.

### **Features:**

Wireless BT

Voice assistant support

AUX Function

Adjustable Headband

Media/Volume control

Call Function

Built-in Rechargeable Battery

## Specification:


BT version	: 5.0
Wireless range	: 10 meters (Without obstacles)
Driver Size	: 40mm
Speaker Impedance	: 32Ω
Frequency Response	: 20Hz - 20kHz
Sensitivity	: 116dB±3dB
Charging time	: 2.5H
Playback time	: 30H*
Talk time	: 30H*
Microphone Impedance	: 1.2kΩ
Microphone Sensitivity	: -38dB±3dB
Net. Weight	: 167g

*\*at 50% Volume*

## Package Contents:

Headphone	: 1 unit
Charging cable	: 1 unit
AUX Cable	: 1 unit

## Product Description:



1. Volume+ / Next Track
2. Multi Functional Button ( MFB )
3. Volume - / Prev. Track
4. Type C charging port
5. AUX port
6. Microphone
7. LED indication

## **Instruction for Use:**

### **Pairing with wireless BT:**

1. Power On the Headphone by long pressing the "**MFB**" button.
2. Enter into BT mode and search for nearby BT devices in your mobile. Tap on the BT name "**ZEB-BANG PRO**" to connect.

### **Call Function:**

Single press the "**MFB**" to answer and hang up the call.

Long press the "**MFB**" to reject the incoming call.

Double press the "**MFB**" to redial the last dialled number.

### **AUX mode:**

Connect one end of the 3.5mm AUX cable to the headphone and the other end of the cable to the audio source. Now the songs played in the audio source will be heard via the headphone.

### **Media Control:**

Use the control buttons in the below mentioned manner to control media and Volume.

Single press the "**MFB**" to Play/Pause the audio.

Short Press the "+"/ "-" button to increase or decrease the volume.

Press and Hold the "+" / "-" button to play the Next or Previous Media.

### **Voice assistant support:**

When the headphone is connected to your mobile phone, press and hold the power button till you hear a tone. This step helps to activate the voice assistant supported by your smart phone.

### **LED Indications:**

**Charging Indication:** RED LED glows

**Full Charge Indication:** RED LED goes Off.

**BT discover Mode:** Blue and Red LED blinks alternately

**BT device connected:** Blue light blinks once in 5 sec.

### **Charging procedure:**

Connect the Type-C charging cable to the charging port of the headphone and the other end to a DC5V adapter.

**ISO 9001:2015 Certified Company**

**[www.zebronics.com](http://www.zebronics.com)**

