ZEBRONICS

Wireless Headphone
ZEB DUKE2

User Manual

Thank you for purchasing **ZEB-DUKE 2** Wireless Headphone. Please read this user manual carefully before operation & save it for future reference.

Note:

• Avoid the use of this product at the high-temperature and high humidity environment.

• Avoid the self-disassembly of the products or it results in the voiding the product's Warranty.

• Please charge the product with power adaptor output rated voltage DC 5V.

• To know more about Terms and conditions for warranty policy, please visit

https://zebronics.com/pages/warranty-policy

Caution:

Listening at High volumes can cause hearing impairment. Please limit your usage at high volumes

Features

Wireless BT / Aux

Voice assistant support

Media/Volume control

Call Function

Dual Pairing

Environmental Noise Cancellation (ENC)

Gaming Mode (Low Latency)

Specification

BT Version	: 5.4
Wireless Range	: 10 meters (Without Obstacles)
Driver Size	: 40mm
Speaker Impedance	: 32Ω
Frequency Response	: 20Hz - 20kHz
Sensitivity	: 120dB±3dB
Charging Time	: 1h 40 minutes
Playback Time	: 60 h*
Talk Time	: 40 h*
Microphone Impedance	: 2.2kΩ
Microphone Sensitivity	: -38dB±3dB
Net. Weight	: 135g

Package Contents

Headphone	: 1 U
Charging Cable	: 1 U
AUX Cable	: 1 U
QR Code Guide	: 1 U

at 50% volume

Product Representation

1 2 3 4 5 6 7

Product Representation
1. Volume+ / Next Track
2. Multi Functional Button
3. Volume- / Prev. Track
4. LED Indicator
5. AUX Input
6. Type C charging port
7. Microphone

Instruction for Use:
Pairing with wireless BT:
1. Power On the Headphone by long pressing the "**MFB**" button.
2. Enter into BT mode and search for nearby BT devices in your mobile. Tap on the BT name "**ZEB-DUKE 2**" to connect.

Call Function:
Single press the "**MFB**" to answer and hang up the call.

Long press the "**MFB**" to reject the incoming call.

AUX mode:

Connect one end of the 3.5mm AUX cable to the headphone and the other end of the cable to the audio source. Now the songs played in the audio source will be heard via the headphone.

Media Control:

Use the control buttons in the below mentioned manner to control media and Volume.

Single press the "**MFB**" to Play/Pause the audio.

Short Press the **"+"/ "-"** button to increase or decrease the volume.

Long Press the **"+" / "-"** button to play the Next or Previous Media.

Gaming Mode (Low Latency):

Double press **"MFB"** to switch between Gaming mode & Music mode.

Voice assistant support:

When the headphone is connected to your mobile phone, press and hold the power button till you hear a tone. This step helps to activate the voice assistant supported by your smart phone.

LED Indications:

Charging Indication: RED LED glows
Full Charge Indication: RED LED goes Off.
BT discover Mode: Blue and Red LED blinks alternately
BT device connected: Blue light blinks once in 5 sec.

Charging procedure:
   Connect the Type-C charging cable to the charging port of the headphone and the other end to a DC5V adapter.