ZEBRONICS

Wireless Headphone
ZEB DUKE
Plus

User Manual

Dear Customer,

Thank you for purchasing **ZEB-DUKE Plus (ZEB-WHP 6)** Wireless headphone. Please read this user manual

carefully before operation and save this user manual for further reference.

Note:

• *Avoid the use of this product at the high temperature and high humidity environment.*

• *Avoid the self-disassembly of the products or it results in voiding the product's Warranty.*

• *Please charge the product with power adapter output rated voltages DC 5V. Avoid using the headphone while charging.*

To know more about Terms and conditions for warranty policy, please visit
https://zebronics.com/pages/warranty-policy

Caution:

Listening at High volumes can cause hearing impairment. Please limit your usage at high volumes

Features

BT v5.4

AUX Function

Environmental Noise Cancellation (ENC)

Soft & Comfortable Earcups

Adjustable Headband

Media/Volume control

Call Function

Built-in Rechargeable Battery

Voice assistant support

Gaming Mode (Low Latency)

Active Noise Cancellation (ANC)

Rapid Charging (10min charge for 200 min* use)

Specification

Model	: ZEB-WHP 6
BT version	: 5.4
Wireless range	: 10 meters (Without obstacles)
Driver size	: 40mm
Speaker Impedance	: 32Ω
Frequency response	: 20Hz - 20k Hz
Sensitivity	: 103±3db
Charging Time	: 2h
Playback time	: 70h*
Standby time	: 400 h
Talk time	: 31h*
Microphone Impedance	: 2.2kΩ
Microphone Sensitivity	: -38±3db
Net. Weight	: 235g

*at 50% Volume(ANC Off)

Product Representation

- Microphone
- LED Indicator
- AUX Input
- Type C Charging Port
- Volume Increase/ Next Track
- MFB
- Volume Decrease/ Previous Track
- ANC Button

General Instruction:

Button Controls:

• Long press "MFB or Power button" to On/Off

• Single press "+" button: Increase Volume

• Single press "-" button: Decrease Volume

• Single press "MFB or Power button" to Play/Pause, Answer/Hang up the phone call

• Long press "+" button for Next Track

• Long press "-" button for Previous Track

• Long press "MFB" until you hear a single beep to activate Voice Assistant function

• Double press the "MFB" to switch between the Gaming/Music mode

• Single press ANC button to activate / deactivate ANC function

Bluetooth Mode:

• The headphone enters BT mode as soon as it is powered ON. (Refer LED indication and make sure aux is not connected already)

• Now search for nearby BT devices in your audio source device.

• Tap on the BT name **"ZEB-DUKE PLUS"** to pair.

Dual Pairing Mode:

• Pair the headphone with one device and do not unpair, now turn off the BT on the first device and pair the headphone with the second device.

• Now you can turn on the first device and the headphone will automatically pair with the first device (if your device is compatible) else tap on ZEB-DUKE PLUS in the BT settings on your first device.

AUX Mode:

• Connect one end of the 3.5mm aux cable to the headphone and connect the other end to any compatible audio source device. (Example: Mobile, Tablet, Laptop, Desktop Computer, etc)

• Media controls can be done via the audio source device. (Make sure to power on the headphone to use BT mode after removing the aux cable)

Gaming Mode (Low Latency):

• Double press the MFB button to enable gaming mode and repeat the process to enter into music mode.

Voice Assistant Support:

• When the headphone is connected with a smart phone, long press the power button for 2 seconds to activate the phone's voice assistant function.

LED Indication:
- Charging – Constant Red LED glows
- Full Charge – Red LED goes OFF
- Bluetooth Discover Mode – Blue and Red LED blinks rapidly
- Bluetooth Connected – Constant Blue LED, then LED goes off
- ANC – Green LED glows when activated and goes off when disabled.

Package Contents

Headphone	: 1 U
Charging cable	: 1 U
Aux cable	: 1 U
QR code guide	: 1 U