



Wireless Headphone

ZEB PARADISE NEO R



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-PARADISE NEO R(ZEB-WHP 11)** Wireless headphone. Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- Avoid the use of this product at the high temperature and high humidity environment.
- Avoid self-disassembly of product or it will result in the failure of warranty.
- Please charge the product with a power adapter of output rated voltage of DC 5V. Avoid using the headphone while charging

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Caution:

Listening at high volumes can cause hearing impairment. Please limit your usage time at high volumes.

Features:

40mm Drivers

Up to 50h* Backup

Rapid Charging (10min charge for 7h* use)

Gaming Mode (Low Latency)

3 EQ Modes

Environmental Noise Cancellation (ENC)

Dual Pairing
Call Function
BT v5.4 | AUX
Voice Assistant Support
Soft ear cushions
Lightweight & Comfortable
Type-C Charging
Built-in Rechargeable Battery

Specification:


Mode	: ZEB-WHP 11
BT version	: 5.4
Wireless range	: 10 Meters (Without obstacles)
Driver Size	: 40mm
Speaker Impedance	: 32Ω
Frequency Response	: 20Hz - 20kHz
Driver Sensitivity	: 99dB±3dB
Charging time	: 1.5h
Playback time	: 50h*
Talk time	: 40h*
Microphone Impedance	: 2.2kΩ
Microphone Sensitivity	: -38±3dB
Net. Weight	: 161g

** at 50% volume(LED off)*

Package Contents:

Headphone	: 1 U
Charging cable	: 1 U
Aux cable	: 1 U
QR code guide	: 1 U

Product Representation



General Instruction:

Button Controls:

- Long press "MFB or Power button" to On/Off
- Single press "+" button: Increase Volume
- Single press "-" button: Decrease Volume
- Single press "MFB or Power button" to Answer/Hang up the phone call
- Long press "+" button for Next Track
- Long press "-" button for Previous Track
- Long press "Play/Pause" until you hear a single beep to activate Voice Assistant function

- Double press the "MFB" to switch between the Gaming/Music mode
- Double press the "Play/Pause" to switch the EQ mode.

Bluetooth Mode:

- The headphone enters BT mode as soon as it is powered ON. (Refer LED indication and make sure aux is not connected already)
- Now search for nearby BT devices in your audio source device.
- Tap on the BT name "**ZEB-PARADISE NEO R**" to pair.

Dual Pairing Mode:

- Pair the headphone with one device and do not unpair, now turn off the BT on the first device and pair the headphone with the second device.
- Now you can turn on the first device and the headphone will automatically pair with the first device (If your device is compatible) else tap on **ZEB-PARADISE NEO R** in the BT settings on your first device.

AUX Mode:

- Connect one end of the 3.5mm aux cable to the headphone and connect the other end to any compatible audio source device. (Example: Mobile, Tablet, Laptop, Desktop Computer, etc.)

- Media controls can be done via the audio source device. (Make sure to power on the headphone to use BT mode after removing the aux cable.)

Gaming Mode (Low Latency):

- Double press the MFB button to enable gaming mode and repeat the process to enter into music mode.

Voice Assistant Support:

- When the headphone is connected with a smartphone, long press the Play/Pause button for 2 seconds to activate the phone's voice assistant function.

LED Indication:

- Charging: Constant Red LED glows
- Full Charge: Red LED goes OFF
- Bluetooth Discover Mode: Blue and Red LED blinks rapidly
- Bluetooth Connected: Constant Blue LED blinks

