



Wireless Headphone

ZEB **PARADISE**

PLUS



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-PARADISE PLUS (ZEB-WHP 8)** Wireless headphone. Please read this user manual carefully before operation and save this user manual for further reference.

Note:

- *Avoid the use of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassembly of the products or it results in voiding the product's Warranty.*
- *Please charge the product with power adapter output rated voltages DC 5V. Avoid using the headphone while charging.*

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Caution:

Listening at High volumes can cause hearing impairment. Please limit your usage at high volumes

Features

Wireless BT v5.4

AUX

Dual Paring

Environmental Noise Cancellation (ENC)

Soft & Comfortable Earcups



Adjustable Headband
Media/Volume control
Call Function
Built-in Rechargeable Battery
Voice assistant support
Gaming Mode (Low Latency)
Rapid Charging (10min charge for 200 min* use)

Specification

Model	: ZEB-WHP 8
BT version	: 5.4
Wireless range	: 10 meters (Without obstacles)
Driver size	: 40mm
Speaker Impedance	: 32Ω
Frequency response	: 20Hz - 20k Hz
Sensitivity	: 103±3db
Charging Time	: 1.5h
Playback time	: 60h*
Standby time	: 400 h
Talk time	: 40h*
Microphone Impedance	: 2.2kΩ
Microphone Sensitivity	: -38±3db
Net. Weight	: 190g

**at 50% Volume*

Product Representation



General Instruction:

Button Controls:

- Long press “MFB or Power button” to On/Off
- Single press “+” button: Increase Volume
- Single press “-” button: Decrease Volume
- Single press “MFB or Power button” to Answer/Hang up the phone call
- Long press “+” button for Next Track
- Long press “-” button for Previous Track
- Long press “Play/Pause” until you hear a single beep to activate Voice Assistant function
- Double press the “MFB” to switch between the Gaming/Music mode

Bluetooth Mode:

- The headphone enters BT mode as soon as it is powered ON. (Refer LED indication and make sure aux is not connected already)
- Now search for nearby BT devices in your audio source device.
- Tap on the BT name **“ZEB-PARADISE PLUS”** to pair.

Dual Pairing Mode:

- Pair the headphone with one device and do not unpair, now turn off the BT on the first device and pair the headphone with the second device.

- Now you can turn on the first device and the headphone will automatically pair with the first device (if your device is compatible) else tap on ZEB-PARADISE PLUS in the BT settings on your first device.

AUX Mode:

- Connect one end of the 3.5mm aux cable to the headphone and connect the other end to any compatible audio source device. (Example: Mobile, Tablet, Laptop, Desktop Computer, etc)
- Media controls can be done via the audio source device. (Make sure to power on the headphone to use BT mode after removing the aux cable)

Gaming Mode (Low Latency):

- Double press the MFB button to enable gaming mode and repeat the process to enter into music mode.

Voice Assistant Support:

- When the headphone is connected with a smart phone, long press the Play/Pause button for 2 seconds to activate the phone's voice assistant function.

LED Indication:

- Charging – Constant Red LED glows
- Full Charge – Red LED goes OFF
- Bluetooth Discover Mode – Blue and Red LED blinks rapidly
- Bluetooth Connected – Constant Blue LED, then LED goes off

Package Contents

Headphone	: 1 U
Charging cable	: 1 U
Aux cable	: 1 U
QR code guide	: 1 U

ISO 9001:2015 Certified Company

www.zebronics.com

