



Wireless Headphone
ZEB THUNDER *Pro*



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-THUNDER PRO** BT headphone. Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- *Avoid the use of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassembly of the products or it results in voiding the product's Warranty.*
- *Avoid using the headphones while charging.*
- *Please charge the product with power adapter output rated voltages DC 5V.*

<https://zebronics.com/pages/warranty-policy>

To know more about Terms and conditions for warranty policy, please visit

Caution:

Listening at High volumes can cause hearing impairment. Please limit your usage at high volumes

Features

Wireless BT, AUX, mSD
Dual Pairing
Type-C Charging
Soft & Comfortable Earcups
Adjustable Headband
Media/Volume Controls
Call Function
Built-in Rechargeable Battery
Voice Assistant
Low Latency Gaming
ENC

Specification


BT version	: 5.3
Wireless range	: 10 meters (Without obstacles)
Driver size	: 40mm
Speaker Impedance	: 17Ω
Frequency response	: 20Hz - 20k Hz
Sensitivity	: 115±3dB
Charging time	: 1.5h
Playback time	: 60 h*
Talk time	: 40 h*
Microphone Impedance	: 1.2kΩ
Microphone sensitivity	: -42dB±3dB
Net. weight	: 175g

*at 50% Volume

Package Contents

Headphone	: 1U
Charging cable	: 1U
Aux cable	: 1U
QR code guide	: 1U

Product Representation



Product Representation

1. MicroSD card slot
2. Single press - Volume decrease /
Long press - Previous track
3. Play/Pause / Voice Assistant

- 4. Single press - Volume increase /
Long press - Next track
- 5. LED indicator
- 6. Power button / Multi-function button (MFB)
- 7. 3.5mm AUX port
- 8. Microphone
- 9. Type-C Charging Port

General Instruction

- Press and hold the multi-function button (MFB) button for 3 seconds to turn ON/OFF the headphone.
- The headphone enters BT mode as soon as it is powered ON.

(Refer LED indication and make sure mSD is not inserted already).

1. Mode Switching

- When aux is connected, the other modes cannot be used until aux is unplugged.
- Press and Hold the Multi-Function button (MFB) for 2 seconds to turn ON Gaming mode low latency after gaming mode enabled again press for 2 seconds to switch to Music mode.

2. Bluetooth Pairing Instruction

- To use BT mode the mSD needs to be removed.

- Enter into Bluetooth mode and search for nearby Bluetooth devices in your mobile.
- Tap on the Bluetooth name ZEB-THUNDER PRO to connect.

3. Call Function

- Single press the Multi function button (MFB) to answer/hang up a call.
- Long press the Multi function button (MFB) for 2 seconds to reject an incoming call.
- Short Press twice on the MFB to Redial.

(This feature works only in BT mode)

4. AUX Mode

- Connect one end of the 3.5mm AUX cable to the headphone and connect the other end to an audio source (Ex. Mobile, Tablet or Laptop/computer)

5. Micro SD Card Mode

- After removing aux cable and then connect mSD to and make sure headphones is turned ON to listen music from mSD.

(Make sure to unplug aux to use mSD mode)

6. Voice assistant support

- When the Headphone is connected to a smart phone via BT, double press the Play/Pause button to wake up the phone's voice assistant.

(This feature works only in BT mode)

LED Indication

- Charging Indication -Constant Red LED glows
- Full Charge Indication - Red LED goes OFF
- Bluetooth Discover Mode - Blue LED flashes Bluetooth
- Device Connected -Stable Blue LED will be lit

(PS. There would be no option to unpair/disconnect BT connected device via headphone MFB.

