



ZEBRONICS
ALWAYS AHEAD

Wireless Headphone
ZEB **THUNDER**



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-THUNDER** Wireless Headphone. Please read the user manual carefully before usage & save it for future reference.

Note:

- *Avoid the usage of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassembly of the products or it results in the voiding the product's Warranty.*
- *Turn off the headphone when it is not in use.*

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Caution:

Listening at High volumes can cause hearing impairment. Please limit your usage at high volumes

Features

BT v5.3

Supports Micro SD

AUX Function

ENC With Low Latency

Soft & Comfortable Earcups

Adjustable Headband

Media/Volume control

Call Function

Built-in Rechargeable Battery

Voice assistant support

Gaming Mode

Specification

BT version : 5.3

Wireless range : 10 meters
(Without obstacles)

Driver size : 40mm

Speaker Impedance : 32Ω

Frequency response : 20Hz - 20k Hz

Sensitivity : $101\pm 3\text{db}$

Charging time : 1.5h

Playback time : 60 h*

Standby time : 400 h

Talk time : 40 h*

Microphone Impedance : 32Ω

Microphone sensitivity : -42 ± 3


Net. weight : 142g

**at 50% Volume*

Package Contents

Headphone	: 1U
Charging cable	: 1U
Aux cable	: 1U
QR code guide	: 1U

Button functions



- 1. ▶- Button** : single press:- Next - / Press and hold :- Volume -
- 2. ▶|| Button** : single press:-Play/Pause /Long press:- Switching between gaming mode and normal mode.
- 3. +◀ Button** : Single press:- Previous / Press


and hold :- Volume +

4. LED indicator

5. Type C charging port

6. AUX input

7. Microphone

8.  key : Double press:- Redial ,Press and hold for few seconds :- Voice assistant and Long press :- Power On/ Power off.

9. mSD input

General instruction:

Charging Instructions:

Connect the one end of the power cable to Headphone and connect the other end to a rated **DC 5V** adapter. The Led glows when it is charging.



BT Mode:

Turn on the Headphone and BT on your phone or tablet. Now search for nearby BT devices and tap on **ZEB-THUNDER** to connect it.

AUX-IN:




The Headphone can be connected to an audio source using a 3.5mm cable. Connect the one end of the cable to the Headphone and the other end to an audio source. The songs from the audio source can be heard through the headphone.

mSD input:

The Headphone automatically switches to mSD input mode when a mSD Card is inserted. The songs from the audio source can be heard through the Headphone (this mode isn't selectable on the Headphone unless a mSD card is inserted). Press The  button to switch to previous audio track and Press the -Button to switch to audio track.

Call Function:

Calling function can be controlled using the inbuilt Buttons which is present on the Headphone.

- double press the  button to accept the Call.
- Press and hold the  Button for few seconds to reject the call.
- Double press the  button to redial a call.

