

 ZEBRONICS

Wireless Headphone
ZEB **THUNDER**  **Max**



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-THUNDER Max** BT headphone. Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- *Avoid the use of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassembly of the products or it results in voiding the product's Warranty.*
- *Avoid using the headphones while charging.*
- *Please charge the product with power adapter output rated voltages DC 5V.*

<https://zebronics.com/pages/warranty-policy>

To know more about Terms and conditions for warranty policy, please visit

Caution:

Listening at High volumes can cause hearing impairment. Please limit your usage at high volumes

Features

Wireless BT, AUX, mSD
Dual Pairing
Type-C Charging
Soft & Comfortable Earcups
Adjustable Headband
Media/Volume Controls
Call Function
Built-in Rechargeable Battery
Voice Assistant
Low Latency Gaming
ENC

Specification


Model No.	: ZEB-WHP 7
BT version	: 5.4
Wireless range	: 10 meters (Without obstacles)
Driver size	: 40mm
Speaker Impedance	: 32Ω
Frequency response	: 20Hz - 20k Hz
Sensitivity	: 115±3dB
Charging time	: 2.5h
Playback time	: 120 h*
Talk time	: 95 h*
Microphone Impedance	: 2.2kΩ
Microphone sensitivity	: -38dB±3dB
Net. weight	: 190g

*at 60% Volume

Package Contents

Headphone	: 1U
Charging cable	: 1U
Aux cable	: 1U
QR code guide	: 1U

Product Representation



Product Representation

1. Single press Play | Pause / Long press Voice Assistant
2. Single press volume increase / Long press next track
3. Single press volume decrease / Long press previous track
4. Power button/Multi-function button(MFB)
5. Type-C charging port
6. 3.5mm AUX port
7. LED indicator

1. General Instruction

- Press and hold the multi-function button (MFB) button for 3 seconds to turn ON/OFF the headphone.
- The headphone enters BT mode as soon as it is powered ON.
- Long press the MFB button to switch between Gaming mode and Music mode.

2. Bluetooth Pairing Instruction

- Enter into Bluetooth mode and search for nearby Bluetooth devices in your mobile.
- Tap on the Bluetooth name ZEB-THUNDER Max to connect.

3. Call Function

- Single press the Multi function button (MFB) to answer/cut a call.
- Long press the Multi function button (MFB) for 2 seconds to reject an incoming call.

4. AUX Mode

- Connect one end of the 3.5mm AUX cable to the headphone and connect the other end to an audio source (Ex. Mobile, Tablet or Laptop/computer)

5. Voice Assistant support

- When the Headphone is connected to a smart phone via BT, Long press the Play/Pause button to wake up the phone's voice assistant.

(This feature works only with in BT mode)

6. LED Indication

- Charging Indication:
Constant Red LED glows
- Full charge indication:
Red LED goes Off
- Bluetooth discover mode:
Blue and Red LED flashes
- Bluetooth device connected:
Blue LED goes off

ISO 9001:2015 Certified Company

www.zebronics.com

