



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-THUNDER MAX**BT headphone. Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- Avoid the use of this product at the high temperature and high humidity environment.
- Avoid the self-disassembly of the products or it results in voiding the product's Warranty.
- Avoid using the headphones while charging.
- Please charge the product with power adapter output rated voltages DC5V.

https://zebronics.com/pages/warranty-policy

To know more about Terms and conditions for warranty policy, please visit

Caution:

Listening at High volumes can cause hearing impairment. Please limit your usage at high volumes

Features

BT v5.4 & AUX Connections

3 EO Modes

Dual Pairing

Voice Assistant Support

Low Latency Gaming mode

Environmental Noise Cancellation (ENC)

Soft & Comfortable Earcushions

Adjustable Headband

Call Function

Built-in Rechargeable Battery

Type-C Charging

Rapid Charging (10 min charge for 10h* use)

Specification

Model No. : ZEB-WHP 7

BT version : 5.4

Wireless range : 10 meters

(Without obstacles)

Driver size : 40mm

Speaker Impedance : 32Ω

Frequency response : 20Hz - 20k Hz

Sensitivity: 115±3dB

Charging time : 2.5h

Playback time : 120 h*

Talk time : 95 h*

Microphone Impedance : $2.2k\Omega$

Microphone sensitivity: -38dB±3dB


Net. weight : 190g

at 50% Volume

Package Contents

Headphone :1U
Charging cable :1U
Aux cable :1U
QR code guide :1U

Product Representation



Product Representation

- 1. Single press Play|Pause/Long press Voice Assistant/Double press to switch EQ Modes
- Single press volume increase / Long press next track
- Single press volume decrease / Long press previous track
- 4. Power button/Multi-function button(MFB)
- 5. Type-C charging port
- 6. 3.5mm AUX port
- 7. LED indicator

1. General Instruction

- Press and hold the multi-function button (MFB) button for 3 seconds to turn ON/OFF the headphone.
- The headphone enters BT mode as soon as it is powered ON.
- Double press the MFB button to switch between Gaming mode and Music mode.
- Double Press the "Play/Pause" to switch between EQ modes.

2. Bluetooth Pairing Instruction

- Enter into Bluetooth mode and search for nearby Bluetooth devices in your mobile.
- Tap on the Bluetooth name ZEB-THUNDER Max to connect.

3. Call Function

- Single press the Multi function button (MFB) to answer/cut a call.
- Long press the Multi function button (MFB) for 2 seconds to reject an incoming call.

4. AUX Mode

 Connect one end of the 3.5mm AUX cable to the headphone and connect the other end to an audio source (Ex. Mobile, Tablet or Laptop/computer)

5. Voice Assistant support

 When the Headphone is connected to a smart phone via BT, Long press the Play/Pause button to wake up the phone's voice assistant.

(This feature works only with in BT mode)

6. LED Indication

- Charging Indication:
 Constant Red LED glows
- Full charge indication:
 Red LED goes Off
- Bluetooth discover mode:
 Blue and Red LED flashes
- Bluetooth device connected:
 Blue LED goes off

ISO 9001:2015 Certified Company www.zebronics.com