



ZEBRONICS
ALWAYS AHEAD

Wireless Headphone
ZEB BANG



User Manual

www.zebronics.com

Thank you for purchasing **ZEB-BANG** BT Headphone. Please read this user manual carefully before operation & save this user manual for future reference.

Note:

- Avoid the use of this product at the high-temperature and high humidity environment.
- Avoid self-disassemble of product, or it will result in the failure of warranty.
- Please charge the product with DC 5V power adaptor.

Caution

Listening at High volumes can cause hearing impairment. Please limit your usage time at high volumes.

Features:

Wireless BT

Voice assistant support

AUX function

Adjustable headband

Media/Volume control

Call function

Built-in rechargeable battery

Specifications:

BT version	: 5.0+EDR
Wireless range	: 10 meters (Without obstacles)
Driver size	: 40mm
Speaker impedance	: 32Ω
Frequency response	: 20Hz - 20kHz
Sensitivity	: 113dB ±3dB
Charging time	: 1.5 H
Playback time	: 20 H*
Talk time	: 20 H*
Microphone impedance	: 1.2kΩ
Microphone sensitivity	: -38dB ±3dB
Net. weight	: 172g

*at 50% Volume

Package contents:

Headphone	: 1 unit
Charging cable	: 1 unit
User manual	: 1 unit

Diagrammatic Representation:



1. Volume-/Prev. track
2. POWER / Play/Pause
3. Volume+/Next track
4. Micro USB charging port
5. 3.5mm AUX port
6. LED indicator
7. Microphone

LED Indication:

Charging Indication: Red LED Glows

Full Charge Indication: Red LED goes OFF

BT Discover Mode: Red & Blue LED Blinks alternatively.

BT Connected to a phone: Blue LED will blink once in an interval of time.

General Instruction:

Bluetooth Pairing Instruction:

Turn on the headphone and search for nearby BT devices in your phone. Tap on the BT name **"ZEB-BANG"** to connect.

- Long press the POWER button to switch ON/OFF the headphones.
- Press the Play/Pause button to Play/Pause a track.
- Short press the Vol+ button to increase volume. Long press the same button to skip to next track.
- Short press the Vol- button to decrease volume. Long press the same button to go back to prev. track.
- Press the Play/Pause key to answer/Hang up a call.
- Press and hold for 2 secs the Play/Pause key to reject an incoming call.
- Double press the Play/Pause key to redial the last number dialed.

Activating smartphone's voice Assistant

When the headphone is connected to a smartphone via BT, long press the Play/Pause key for 2 secs to wake up your smartphone's voice assistant.

AUX Mode

Connect one end of the AUX cable to the headphone. Connect the other end to an audio source (Ex. Mobile, Computer). The songs played by the audio source can be heard through the headphone.

