



Wireless Earbuds

ZEB Dh'vny E11



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing ZEB-DH'VNY E11 (Wireless Earbuds). Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- *Avoid the usage of this product in high temperature and high humidity environments.*
- *Avoid the self-disassembly of the product, as it will void the warranty.*
- *Please charge the product with a DC 5V power adapter.*

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Caution:

Listening at high volumes can cause hearing impairment. Please limit your usage time at high volumes.

Features:

- Upto 45h* Backup
- Rapid Charging (10min charge for 120min* use)
- Gaming Mode (Low Latency)
- Environmental Noise Cancellation (ENC)
- Dual EQ Modes
- Built-in Quad MIC
- 10mm Drivers

- Flash Connect
- Splash proof
- BT v5.4
- Call Function
- Voice Assistant support
- Touch Controls
- Type-C Charging
- Neodymium magnets

Specifications:


Model No.	: ZEB-Pods zi 14
BT Version	: v5.4
Supported BT Profile	: AVCTP / HFP/ A2DP / AVRCP / AVDTP
Drive Size	: 10mm
Speaker Impedance	: 32Ω
Playback Time	: 8.5h
Charging Time	
Earphone	: 1.5h
Case	: 1.5h
Talk Time	: 6h*
Standby Time	: 180 days
Case Dimension	
(W x D x H)	: 5.8 x 2.5 x 4.8 cm
Package Dimension	
(W x D x H)	: 12 x 4 x 16 cm
Net. Weight	: 39g

** at 70% Volume*

Package Content:

Earbuds	: 2 U
Charging case	: 1 U
Ear tips	: 4 U
Charging cable	: 1 U
QR Code Guide	: 1 U

Product Representation:



Usage Instruction:

BT Pairing Instructions:

Step 1: The ear buds enter pairing mode as soon as the buds taken out from the case.

Step 2: Both the ear buds will pair with each other within 5 seconds right after both the buds taken out from the case.

Step 3: Now open the phone's BT settings and pair the ear buds by tapping on the "**ZEB-DH'VNY E11**" in the phone's BT list.

Ear Buds Functions:

- Long press the MFB for 3 seconds on either of the ear bud to activate the voice assistance of your BT connected device, if your device is compatible.
- To power On the ear buds press & hold the MFB on either of the ear buds for 5 seconds.
- To power Off the ear buds press & hold the MFB on either of the ear buds for 5 seconds.

During Music Playback:

- Single Tap the MFB once on either side of the ear bud to Play/Pause the music.
- Double Tap the MFB on the Left/Right side to Prev./Next track.
- Triple tap the MFB on the Left/Right side to Decrease/Increase Volume.

During Calls:

- Single tap the MFB on either side of the earbuds to answer the call.
- Single tap the MFB on either side of the ear buds to reject the call.
- Press & Hold on either side of the ear buds for direct call reject.

Mode Switch:

- Tap 4 times the MFB on the Right earbuds to Switch between Equalizer mode & Sound monster mode.
- Tap 4 times the MFB on the Left earbuds to Switch between Gaming mode and Music mode.

Charging instruction:

Charging the Case:

- Connect the Type-C cable to the charging port of the charging case and connect the other end of the cable to the DC 5V adapter.
- Check the LED indicator once plugged in it flashes orange color. Once it fully charged the LED indicator shows orange Glow.

Charging the Earbuds:

Place the ear buds in the respective slots of the charging case and close the lid of the charging case. Once placed in the charging case, the ear buds will charge automatically.

