



Wireless Earbuds
ZEB FIREFLIES



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-FIREFLIES** (Wireless Earbuds). Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- *Avoid the usage of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassembly of the products or it results in voiding the product's Warranty.*

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Caution:

Listening at high volumes can cause hearing impairment. Please limit your usage time at high volumes.

Features

BT v5.4

Gaming mode (Low latency)

Environmental Noise Cancellation (ENC)

Up to 23h* Backup

Splash proof

13mm Drivers

Voice assistant

Touch control

Call function
Type-C charging

Specifications


BT Version : v5.4
Supported
BT Profile : HSP / SPP / A2DP / AVRCP
Drive size : 13mm
Speaker
impedance : 32Ω
Playback time : 23 h*
Charging time
 Earphone : 1.5 h
 Case : 1.5h
Talk time : 3 h*
Standby time : 70 h
Case dimension : 5.7 x 2.4 x 4.7 cm
 (W x D x H)
Net. Weight : 32g

**at 50% Volume*

Package contents

Earbuds : 2 U
Charging Case : 1 U
Charging Cable : 1 U
QR Code Guide : 1 U

Product Representation



Usage Instruction:

BT Pairing Instructions:

- Once the ear buds are out of the case they enter BT pairing mode.
- The ear buds will pair with each other within 2 seconds once both are out of the case.
- Open the phone's BT settings and click pair upon tapping on the name "ZEB-FIREFLIES"

Ear Buds Functions:

- Touch and hold for 2 seconds on the left ear bud to activate the voice assistance

function of your source device.

- Touch and hold for 2 seconds on the right ear bud to enable low latency Gaming mode or Music mode.

- To power off the ear buds long press the MFB on either of the ear buds for 5 seconds.

- To power on the ear buds long press the MFB on both the ear buds for 3 seconds.

During Music Playback:

- Single touch on the Left/Right ear bud to Play or Pause the playback.

- Double tap on the Left/Right ear bud to skip to the Previous/Next track.

- Triple tap on the left ear bud to decrease volume and on the right ear bud to increase volume.

During Calls:

- Single touch either side of the ear buds to answer or hang up the ongoing call.

- Touch and hold either side of the ear buds for 2 seconds to reject incoming call.

Charging instruction:

Charging the Case:

- Plug the Type-C connector into the Type-C charging port of the ear bud's charging case and connect the other end of the cable to the DC 5V power source.

- The corresponding LED indicator will glow on the case, while the case is charging. LED Indicator will be off, upon full charge.

Charging the Earbuds:

The ear buds will automatically charge in the respective slots once placed in the charging case. There will be a constant LED indication on the buds as well as the case while charging and the light goes off upon full charge.