

 ZEBRONICS

Wireless Earbuds

ZEB **PODS 131**



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-PODS 131** (Wireless Earbuds). Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- *Avoid the usage of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassembly of the products or it results in voiding the product's Warranty.*

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Caution:

Listening at high volumes can cause hearing impairment. Please limit your usage time at high volumes.

Features

BT v5.4

Gaming Mode (Low Latency)

Environmental Noise Cancellation (ENC)

Up to 22h* Backup

Splash Proof

10mm Drivers

Voice Assistant

Touch Control

Call Function

Type-C Charging

Specifications


Model	: ZEB-PODS zi 8
BT Version	: 5.4
Supported	
BT Profile	: HSP / SPP / A2DP / AVRCP
Drive size	: 10mm
Speaker	
impedance	: 26Ω
Playback time	: 24h*
Charging time	
Earphone	: 1.5 h
Case	: 1.5 h
Talk time	: 5 h*
Standby time	: 60 h
Case dimension	: 5.6 x 2.4 x 4.5 cm (W x D x H)

**at 50% Volume*

Package contents

Earbuds	: 2 U
Charging Case	: 1 U
Ear tips	: 4 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

Product Representation



Usage Instruction:

BT Pairing Instructions:

- Once the ear buds are out of the case they enter BT pairing mode.
- The ear buds will pair with each other within 2 seconds once both are out of the case.
- Open the phone's BT settings and click pair upon tapping on the name **"ZEB-PODS 131"**

Ear Buds Functions:

- To power on the ear buds long press the Touch control on both the ear buds for 3 seconds.

- To power off the ear buds long press the Touch control on either of the ear buds for 5 seconds.

- Touch and hold for 2 seconds on the right ear bud to enable low latency Gaming mode or Music mode.

- Touch and hold for 2 seconds on the left ear bud to activate the voice assistance function of your source device.

During Music Playback:

- Single touch on the Left/Right ear bud to Play or Pause the playback.

- Double tap on the Left/Right ear bud to skip to the Previous/Next track.

- Triple touch on the left/right ear buds to increase/decrease the volume

During Calls:

- Single touch either side of the ear buds to answer or end the ongoing call.

- Touch and hold either side of the ear buds for 2 seconds to decline incoming call.

Charging instruction:

Charging the Case:

- Plug the Type-C connector into the Type-C charging port of the charging case and connect the other end of the cable to the DC 5V power source.

- The corresponding LED indicator will blink on the case, while the case is charging. LED Indicator will glow constant, upon full charge.

Charging the Earbuds:

- The ear buds will automatically charge once placed in the charging case.

- There will be a constant LED indication on the buds while charging and the light goes off upon full charge.

ISO 9001:2015 certified company
www.zebronics.com

