



Wireless Earbuds
ZEB PODS141R



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-PODS 141R** (Wireless Earbuds). Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- *Avoid the usage of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassembly of the products or it results in voiding the product's Warranty.*
- *Please charge the product with DC 5V power adapter*

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Caution:

Listening at high volumes can cause hearing impairment. Please limit your usage time at high volumes.

Features

- Wireless Stereo Sound
- Upto 35h* Battery Life with Charging Case
- Voice Assistant Support
- Splash Proof
- Call Function
- Type-C Charging
- Built-In Rechargeable Battery

- Quad Mic with Environmental Noise Cancellation (ENC)
- Gaming Mode (Low Latency)
- Flash Connect
- Rapid Charging (10min charge for 120min* use)
- Dual Pairing
- Dual EQ Modes

Specifications

BT Version	: v5.3
Supported BT Profile	: HFP, A2DP, AVRCP
Drive Size	: 10 mm
Speaker Impedance	: 32Ω
Playback Time	: 7 h*
Charging Time	
Earphone	: 50 min
Case	: 2 h
Talk Time	: 3 h*
Standby Time	: 100h
Case Dimensions	: 5.5 x 2.8 x 4.5 cm
(W x D x H)	
Net Weight	: 38g

**at 50% Volume*

Package Contents

Earbuds	: 2 U
Charging Case	: 1 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

Product Representation



Usage Instruction:

BT Pairing Instructions:

Step 1: The ear buds enter pairing mode as soon as the buds taken out from the case.

Step 2: Both the ear buds will pair with each other within 5 seconds right after both the buds taken out from the case.

Step 3: Now open the phone's BT settings and pair the ear buds by tapping on the "**ZEB-PODS 141R**" in the phone's BT list.

Ear Buds Functions:

- Long press the MFB for 3 seconds on the

left ear bud to activate the voice assistance of your BT connected device, if your device is compatible.

- To power On the ear buds press & hold the MFB on either of the ear buds for 3 seconds.
- To power Off the ear buds press & hold the MFB on either of the ear buds for 5 seconds

During Music Playback:

- Single Tap the MFB once on either side of the ear bud to Play/Pause the music.
- Double Tap the MFB on the Left/Right side to Prev./Next track.
- Triple tap the MFB on the Left/Right side to Decrease/Increase Volume

During Calls:

- Single tap the MFB on either side of the earbuds to answer the call.

Mode Switch:

- A single Tap followed by a long press for 3 sec on either of the side to Switch between Equalizer mode & Sound monster mode
- Press & Hold the MFB on the Left earbuds to Switch between Gaming mode and Music mode.
- Single tap the MFB on either side of the ear buds to reject the call.
- Press & Hold on either side of the ear buds for direct call reject.

Charging Instruction:

Charging the Case:

- Connect the Type-C cable to the charging port of the charging case and connect the other end of the cable to the DC 5V adapter.
- Red LED blinks when the case is charging and the Red LED Glows constant upon full charge.

Charging the Earbuds:

Place the ear buds in the respective slots of the charging case and close the lid of the charging case. Once placed in the charging case, the ear buds will charge automatically.

