



Wireless Earbuds

ZEB **PODS**A21



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-PODS A21** Wireless Earbuds. Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- Avoid the usage of this product at the high temperature and high humidity environment.
- Avoid the self-disassembly of the products or it results in voiding the product's warranty.
- Please charge the product with DC 5V power adapter.

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Caution:

Listening at high volume can cause hearing impairment. Please limit your usage time at high volume.

Features:

- Wireless Stereo Sound
- Upto 30h* backup
- Dual EQ Modes
- Active Noise Cancellation (ANC)
- Gaming Mode (Low Latency)
- Quad Mic with Environmental Noise Cancellation (ENC)
- Transparency Mode

- Splash Proof
- BT v6.0
- Call Function
- Voice Assistant Support
- Touch Control
- Type-C Charging
- AAC Support
- Built-In Rechargeable Battery

*at 50% Volume



Specifications:

BT Version	: v6.0
Supported BT Profile	: HFP, A2DP, AVRCP
Drive Size	: 13 mm
Speaker Impedance	: 32Ω
Playback Time	: 30 h*
Charging Time	
Earphone	: 1h
Case	: 1.5 h
Talk Time	: 3-4 h*
Standby Time	: 150 h
Case Dimension	
(W x D x H)	: 6.2 x 2.7 x 4.6 cm
Net. Weight	: 41 g

Package Content:

Earbuds	: 2 U
Charging Case	: 1 U
Charging Cable	: 1 U
Eartips	: 4 U
QR Code Guide	: 1 U

Product Representation:



Usage Instruction

BT Pairing Instructions:

Step 1: The earbuds enter pairing mode as soon as the buds are taken out from the case.

Step 2: Both the earbuds will pair with each other within 5 seconds.

Step 3: Now open the phone's BT settings and pair the earbuds by tapping on the **"ZEB-Pods A21"** in the phone's BT list.

During Music Playback:

- Single tap the MFB once on either side of the earbud to Play / Pause the music.
- Double tap the MFB on Left / Right side of the earbud to skip to Previous / Next track
- 3 tap the MFB on left side of the earbud to switch between Gaming Mode and Music Mode and 3 tap the MFB on right side of the earbud to switch between 2EQ modes
- 4 tap the MFB on Left / Right side of the earbud to Decrease/ Increase volume.

During calls:

- Single tap the MFB on either side of the earbuds to answer/end the call.
- Press & hold the MFB on either of the earbuds to reject the call.

Gaming Mode:

Tap the MFB three times on the left side to enable gaming mode. To disable gaming mode again 3 times tap on the left side MFB to revert to music mode.

EQ mode:

By default it will be Equalizer Mode, then three times tap the right earbud once again to switch between 2EQ modes.

Activating Voice Assistant:

After connecting the earbuds via BT, long press the MFB on left sides for 4 sec to wake up the Voice Assistance of your smartphone.

ANC Mode:

Long press the MFB on right side for 4 sec to switch between mode:

- **MODE 1** ►► Transparency Mode
- **MODE 2** ►► ANC ON
- **MODE 3** ►► ANC OFF

Power on/ off (Manual Method):

Press and hold the MFB on either sides for 7 sec to turn off the TWS, press and hold the MFB on both side for 4 sec to turn on the TWS.

Charging Instruction

Charging the Case:

Connect the Type-C cable to the charging port of the charging case and connect the other end of the cable to the DC 5V adapter.

Charging the Earbuds:

Place the earbuds in the respective slots of the charging case and close the lid of the charging case. Once placed in the charging case, the earbuds will charge automatically.