



Wireless Earbuds

PODS B31



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-PODS B31** (Wireless Earbuds). Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- *Avoid the usage of this product at the high temperature and high humidity environment.*
 - *Avoid the self-disassembly of the products or it results in voiding the product's Warranty.*
 - *Please charge the product with DC 5V power adapter*
- To know more about Terms and conditions for warranty policy, please visit*

<https://zebronics.com/pages/warranty-policy>

Caution:

Listening at high volumes can cause hearing impairment. Please limit your usage time at high volumes.

Features:

- Wireless Stereo Sound
- Upto 28h* battery life with Charging Case
- Voice Assistant Support
- Splash proof
- Type-C Charging
- Built-In Rechargeable Battery
- Gaming Mode
- Touch Control

Specifications:

Model No.	: Zeb-Pods Zi 16
BT Version	: v6.0
Supported BT Profile	: HFP, A2DP, AVRCP
Drive Size	: 13mm
Speaker Impedance	: 32Ω
Playback Time	: 28h*
Charging Time	
Earphone	: 50min
Case	: 1.5h
Talk Time	: 3-4h*
Standby Time	: 150h
Case Dimension	
(W x D x H)	: 5.8 x 2.6 x 4.6 cm
Package Dimension	
(W x D x H)	: 11.1 x 12.4 x 3.1 cm
Net. Weight	: 32g

*at 50% Volume

Package Content:

Earbuds	: 2 U
Charging case	: 1 U
Charging cable	: 1 U
QR Code Guide	: 1 U
Eartips	: 4 U

Product Representation:



Usage Instruction:

BT Pairing Instructions:

Step 1: The ear buds enter pairing mode as soon as the buds taken out from the case.

Step 2: Both the ear buds will pair with each other within 5 seconds

Step 3: Now open the phone's BT settings and pair the ear buds by tapping on the **ZEB-PODS B31** in the phone's BT list.

During Music Playback:

1. Single tap the MFB on left/right side of the earbud to Decrease/ Increase volume.
2. Double tap the MFB on either side to Play / Pause the track
3. Three tap the MFB on Left / Right side of the

earbud to skip to Previous / Next track

4. 4 tap the MFB on either side of the earbud to switch between gaming and music mode

During calls:

1. Double tap the MFB on either side of the earbuds to answer/end the call
2. Press & hold the MFB on either of the earbuds to reject the call

Gaming Mode:

Tap the MFB four times on either side to enable gaming mode. To disable gaming mode again 4 times tap on the either side MFB to revert to music mode.

Activating Voice Assistant:

After connecting the earbuds via BT, long press the MFB on either sides for 4 sec to wake up the Voice Assistance of your smartphone

Turning on/ off (Manual Method)

Press and hold the MFB on either sides for 7 sec to turn off the TWS , press and hold the MFB on both side for 4 sec to turn on the TWS

Charging Instruction:

Charging the Case:

Connect the Type-C cable to the charging port of the charging case and connect the other end of the cable to the DC 5V adapter.

Charging the Earbuds:

Place the ear buds in the respective slots of the charging case and close the lid of the charging case. Once placed in the charging case, the ear buds will charge automatically.