



Wireless Earbuds
ZEB **PODS I**



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-PODS I** Wireless Earbuds. Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- Avoid the use of this product at the high temperature and high humidity environment.
- Avoid self-disassembly of product or it will result in the failure of warranty.
- Please charge the product with DC 5V power adapter.
- There isn't no specific way to turn ON & OFF ENC. It automatically enables during calls.

Caution:

Listening at high volume can cause hearing impairment. Please limit your usage time at high volume.

Features

- Wireless Stereo Sound
- Upto 22 h* (ANC ON) battery life with Charging Case
- Upto 28 h* (ANC OFF) battery life with Charging Case
- Voice Assistant Support
- Splash proof
- Call Function
- Type-C Charging
- Built-In Rechargeable Battery
- Environmental Noise Cancellation (ENC)
- Active Noise Cancellation (ANC)

- Gaming Mode (Low Latency)
- Flash Connect

Specifications:

BT Version	: v5.2
Supported BT Profile	: HSP / HFP / A2DP / AVRCP
Drive Size	: 13mm
Speaker Impedance	: 32Ω
Playback Time	
ANC ON	: 6h*
ANC OFF	: 7h*
Charging Time	
Earphone	: 1 h
Case	: 2 h
Talk Time	: 4-5 h (ANC OFF)
Standby Time (Earbuds)	: 40 h
Case Dimension (WxDxH)	: 6 x 5.7 x 3.6 cm
Net Weight	: 45g

Package Contents

Earbuds	: 2 U
Charging case	: 1 U
Eartips	: 4 U
Charging cable	: 1 U
QR Code Guide	: 1 U

**at 50% Volume*

Product Representation

Earbud



Case



Music Playback:

- Single Tap the MFB once on either side to Play/Pause the Track.
- Double tap on Left side to Skip to the Previous song.
- Double tap on Right side to Skip to the Next song.

During Calls:

While receiving a call....

- Single tap the MFB on either side of the earbuds to Answer / End the call.
- Press & Hold the MFB on either of the earbuds to Reject the call.

Activating the Voice Assistant:

Triple tap the MFB button on the left side for 3 sec to wake up the Voice assistance from your smartphone.

Activating Gaming mode:

- Triple tap the MFB on the Right side to trigger Gaming Mode.
- Triple tap once again on the Right side MFB to Revert to Music Mode.

Turning OFF/ON (Manual Method)

- By Press and holding the MFB on both the sides for 5 secs can Turn OFF TWS.
- Do the same to turn back ON TWS.

ANC Mode (Active noise cancellation)

Press and hold either one of the TWS to switch modes.

- MODE 1 ►► ANC ON
- MODE 2 ►► ANC OFF
- MODE 3 ►► AMBIENT MODE

Usage Instructions:

BT Pairing Instructions:

Step 1: The earbuds will turn ON once it is taken out from the case.

Step 2: The earbuds will pair with each other within 5 secs.

Step 3: Now open the phone's BT settings and pair the earbuds by clicking on the "ZEB-PODS 1".

Charging Instructions:

Charging the Case:

Connect the Type-C cable to the charging port of the charging case and connect the other end of the cable to the DC5V adapter.

The charging case Red LED will blink and once its fully charged Green LED will glow, indicating that the charging case is full.

Charging the Earbuds:

Put the earbuds in the respective charging slot of the charging case. Once placed in the charging case, the earbuds will charge automatically.

ISO 9001:2015 certified company

www.zebronics.com

