



Wireless Earbuds

ZEB **PODS K3**



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-PODS K3** (Wireless Earbuds). Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- *Avoid the usage of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassembly of the products or it results in voiding the product's Warranty.*
- *Please charge the product with DC 5V power adapter*

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Caution:

Listening at high volumes can cause hearing impairment. Please limit your usage time at high volumes.

Features

Wireless Stereo Sound

Upto 40h* battery life with Charging Case

Voice Assistant Support

Splash proof

Type-C Charging

Built-In Rechargeable Battery

Quad Mic with Environmental Noise
Cancellation (ENC)
Gaming Mode (Low Latency)
Dual EQ modes
Flash Connect

Specifications

BT Version	: v5.4
Supported	
BT Profile	: HFP, A2DP, AVRCP
Drive Size	: 10 mm
Speaker	
Impedance	: 32Ω
Playback Time	: 4-5 h*
Charging Time	
Earphone	: 50 min
Case	: 2 h
Talk Time	: 2 - 2.5 h*
Standby Time	: 150h
Case Dimensions	
(W x D x H)	: 5.93 x 2.21 x 5.51 cm
Net Weight	: 42g

**at 50% Volume*

Package Contents

Earbuds	: 2 U
Charging case	: 1 U
Charging Cable	: 1 U
QR code guide	: 1 U

Music Play Back:

- Single Tap the MFB once on either side to Play/Pause the Track.
- Double tap on Left side to Skip to the Previous song.
- Double tap on Right side to Skip to the Next song.
- Triple tap on Right side to increase the volume (vol/+)
- Triple tap on Left side to Decrease the volume (vol/-)
- Long press the MFB Button on the Right side for 3 seconds to wake up the voice assistant.

During Call:

While receiving a call

- Single Tap the MFB once on either side of the ear bud to Answer the call.
- Double Tap the MFB on either side of the earbuds to Decline the call.
- Long press the MFB on either of the earbuds to Reject the call.

Dual/EQ mode:

Equalizer/sound monster mode:

- Tap 4 times on either side of the MFB to enable the Equalizer/sound monster modes.

Gaming/music mode:

- Long press the MFB on the Left side to enable the gaming/music modes.

Turning OFF/ON (Manual Method):

- By Press and holding the MFB on both the sides for 5 secs can Turn OFF TWS.
- Do the same to turn back ON TWS.

Usage Instruction:

BT Pairing Instructions:

Step 1: The earbuds will turn ON once it is taken out from the case.

Step 2: The earbuds will pair with each other within 5 secs.

Step 3: Now open the phone's BT settings and pair the earbuds by clicking on the **"ZEB-PODS K3"**

Charging Instructions:

Charging the Case:

Connect the Type-C cable to the charging port of the charging case and connect the other end of the cable to the DC5V adapter.

Charging the Earbuds:

Put the earbuds in the respective charging

slot of the charging case. Once placed in the charging case, the earbuds will charge automatically.

CHARGING INDICATIONS:

Green Light - Fully charge Indication

Red Light - Low Battery Indication

ISO 9001:2015 certified company

www.zebronics.com

A decorative zebra print pattern in shades of gray and white, located at the bottom of the page.