ZEBRONICS

Wireless Earbuds
ZEB SOUND BOMB 10

User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-SOUND BOMB 10** Wireless Earbuds. Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- Avoid the use of this product at the high temperature and high humidity environment.
- Avoid self-disassembly of product or it will result in the failure of warranty.
- Please charge the product with DC 5V power adapter.

Caution:

Listening at high volumes can cause hearing impairment. Please limit your usage time at high volumes.

Features

- Wireless Stereo Sound
- Upto 40 h* battery life with Charging Case
- Voice Assistant Support
- Splash proof
- Call Function
- Type-C Charging
- Built-In Rechargeable Battery
- Environmental Noise Cancellation (ENC)
- Gaming Mode
- Flash Connect

Specifications

BT Versionv	: 5.2
Supported BT Profile	: SPP/HSP/A2DP/AVRCP
Drive Size	: 10mm
Speaker Impedance	: 16Ω
Playback Time	: 4.35 h*
Charging Time	
Earphone	: 1 h
Case	: 1.5 h
Talk Time	: 2.5-3 h
Standby Time	: 30 h (Earbuds)
Case Dimension	: 57 x 33 x 45 mm (WxDxH)
Net Weight	: 40g

Package Contents

Earbuds	: 2 U
Charging Case	: 1 U
Eartips	: 4 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

at 50% Volume

Product Representation

Case

LED
Indicator

Earbud

MFB Touch Control

Type-C Charging
Port

Music Playback:
Earbuds Functions

- Single tap the MFB on either sides to Play/Pause the Track.
- Double tap on Left side to play the Previous song.
- Double tap on Right side to skip to Next song.
- Press the MFB button on the Left side earbud for 3 sec to activate voice assistance.
- Press the MFB button on the Right side earbud for 3 sec to switch from Music mode to Gaming mode and vice versa.

During Calls:

- Single tap the MFB on either side of the earbuds to answer / end the call.
- Press & Hold the MFB on either of the earbuds to reject the call.

Mode Switching:

Press & Hold the MFB on Right side of the earbud for 3secs to switch from Music mode to Gaming mode and vice versa.

Power On/Off:

Press & Hold the MFB on either sides of earbuds to Power On/off .

Usage Instructions:

BT Pairing Instructions:

Step 1: The earbuds will turn On once it is taken out from the case.

Step 2: The earbuds will pair with each other within 5 sec.

Step 3: Now Turn ON the phone's BT - search for "**ZEB-SOUND BOMB 10**" - Tap and connect.

Activating the Voice Assistant:

After connecting the earbuds via BT, Long press the MFB button on the left side earbud for 3 sec to wake up the Voice assistance of your smartphone.

Charging Instructions:

Charging the Case:

Connect the Type-C cable to the charging port of the charging case and connect the other end of the cable to the DC5V adapter.

The charging case Red LED will blink and once its fully charged Green LED will glow, indicating that the charging case is full.

Charging the Earbuds:

Put the earbuds in the respective charging slot of the charging case. Once placed in the charging case, the earbuds will charge automatically.