



Wireless Neckband Earphone

ZEB **ESCAPE 100**



User Manual

www.zebronics.com

Dear Customer,

Thank You for purchasing **ZEB-ESCAPE 100** wireless neckband earphone. Please read this user manual carefully before operation & save it for future reference.

Note:

- *Please full charge the product with a power adapter output rated DC 5V before first time usage.*
- *Avoid the self-disassembly the product or it results in the voiding the product's warranty.*
- *To know more about Terms and conditions for warranty policy, please visit*

<https://zebronics.com/pages/warranty-policy>

Caution:

Listening at high volumes can cause hearing impairment. Please limit your usage time at high volumes.

Features:

- Upto 30h* backup
- MagSnap
- 10mm Drivers
- 5 Voice Changing Effects for Calls
- Voice assistant support
- Gaming Mode (Low Latency)
- BT v5.4
- Flexible Neckband
- Type-C Charging
- Built-In Rechargeable Battery
- Rapid Charging (10min charge = 10h* use)

- Volume & Media control
- Call Function

Specifications:


Model	: ZEB-SNB 3
BT Version	: V5.4
Supported BT Profile	: AVRCP, A2DP
Drive Size	: 10mm
Speaker Impedance	: 16Ω
Playback Time	: 30h*
Charging Time	: 1h
Standby Time	: 200h
Talk Time	: 20h*
Package Dimension (W x D x H)	: 18 x 3 x 22 cm
Net. Weight	: 31g

** at 50% Volume*

Package Content:

Neckband	: 1 U
Charging Cable	: 1 U
QR Code Guide	: 1 U
Eartips	: 4 U

Product Representation:



1.-Button:

Single press: Volume Down

Long press: Previous Track

2. MFB Button:

Single Press: Play/Pause

Double Press: Redial

Triple Press: Gaming Mode/ Music mode

Long Press: Power On/ Off manually

3. +Button:

Single Press: Volume up

Long Press: Next Track

4. LED Indicator

5. Voice Function Button:

Single press: Voice changing effect during Call

Long Press: Activate voice assistant

6. Type-C charging

LED Indication:

1	Charging the Neckband	Red light glows - (charging) Blue Light Glows - Fully charged
2	BT pairing	Red and blue blinks - BT discovery mode Blue blinking - BT paired successfully

Usage Instruction

STEP 1 – Separate the earbuds to activate the device. The earbuds will enter pairing mode automatically with Red & Blue LED blinking alternately.

STEP 2 – Turn ON Bluetooth on your mobile phone and search for the BT name **“ZEB-ESCAPE 100”**

STEP 3 – Once the BT name is visible in your mobile phone tap to connect it.

Power On/Off:

- The **Magsnap** function allows the earbuds to power **Off automatically** when snapped together, and **Power On** when pulled apart.

Activating Smart Phone's Voice assistant:

- When the neckband is connected to a mobile phone, Press and hold the **voice function button** for 3 seconds to activate voice assistant.

Note:

Smart phone should have an active internet connection to use the voice assistant function.

Call Function:

- Single press the **MFB** button to attend / end the call and long press to reject the incoming call
- Double press the **MFB** button for redialing
- During a call, press the **Voice Function Button** once to switch between the available voice effects.

Available Voice Modes:

- Original Voice Mode
- Sound Monster Mode
- Low Pitch Mode
- Magic Voice Mode
- High Pitch Mode 1
- High Pitch Mode 2

Note:

The selected voice effect will be heard by the person on the other end of the call.

Charging Instruction:

- Connect the Type-C charging cable to the charging port of the Neckband & connect the other end to the DC 5V adapter.

