ZEBRONICS

Wireless Neckband Earphone

ZEB ESCAPE 80

User Manual

www.zebronics.com

Thank You for purchasing **ZEB-ESCAPE 80** wireless neckband earphone. Please read this user manual carefully before operation & save it for future reference.

Note:

• *Please full charge the product with a power adapter output rated DC 5V before first time usage.*

• *Avoid the self-disassembly the product or it results in the voiding the product's warranty.*

To know more about Terms and conditions for warranty policy, please visit

https://zebronics.com/pages/warranty-policy

Caution:

Listening at high volume can cause hearing impairment. Please limit your usage time at high volume.

Features

Upto 18h* backup
MagSnap
10mm Drivers
Call Function
Voice assistant support
BT v5.3
Flexible Neckband

Type-C Charging
Built-In Rechargeable Battery
Rapid Charging
(10min charge for 100min* use)
Environmental Noise Cancellation (ENC)
Gaming Mode (Low Latency)
Volume & Media control

Specifications

Model	: ZEB-SNB 1
BT Version	: v5.3
BT Profile	: AVRCP, A2DP
Drive size	: 10mm
Speaker impedance	: 32Ω
Playback time	: 18h*
Charging time	: 1.5 h
Standby Time	: 200 h
Talk Time	: 20h*
Net. weight	: 25g

Package contents

Neckband	: 1 U
Charging Cable	: 1 U
Eartips	: 4 U
QR Code Guide	: 1 U

at 50% volume

Product Representation

1. **+ Button**

   Short press: Volume up

   Long press: Next track

2. **MFB Button**

   Single press: Play / Pause

   Press and hold for 3 seconds: Voice assistant

   Long press and hold: Power On/ Power off

   When calling (MFB Button on Middle):-

   Single press: Accept / End the ongoing call

   Double press: Direct incoming Call rejection

   Double press: Redial

3. **– Button**

   Short press: Volume down

   Long press: Previous track

Usage Instruction

Bluetooth Pairing Instructions:

STEP 1 - Press and hold the MFB button to power ON the earphones.

STEP 2 - Switch ON the BT in your mobile phone & search for the BT name **"ZEB-ESCAPE 80"**

STEP 3 – Once the BT name is visible in your mobile phone, tap to connect it.

Activating Smart Phone's Voice Assistant

When the neckband is connected to a mobile phone, Press and hold the **MFB** Button for 3 seconds to activate voice assistant.

Note: Smart phone should have an active internet connection to use the voice assistant function.

Call Function:

• Single press the **MFB** button to attend / end the Call and Double press to reject the incoming call.

• Double press the **MFB** button for Redialing.

Led Indication

1	Charging the Neckband	Red light glows-(charging) Blue Light Glows - Fully charged
2	BT pairing	Red and blue blinks – BT discovery mode Blue blinking - BT paired successfully
3	Power on / off	Blue Blinking – while power On Red Blinking – while power Off

Charging Instruction

Connect the Type-C charging cable to the charging port of the Neckband & connect the other end to the DC 5V adapter.