



Wireless Neckband Earphone

**ESCAPE 90**



# User Manual

[www.zebronics.com](http://www.zebronics.com)

## **Dear Customer,**

Thank You for purchasing **ZEB-ESCAPE 90** wireless neckband earphone. Please read this user manual carefully before operation & save it for future reference.

### **Note:**

- *Please full charge the product with a power adapter output rated DC 5V before first time usage.*
- *Avoid the self-disassembly the product or it results in the voiding the product's warranty.*
- *To know more about Terms and conditions for warranty policy, please visit*

*<https://zebronics.com/pages/warranty-policy>*

### **Caution:**

Listening at high volumes can cause hearing impairment. Please limit your usage time at high volumes.

### **Features:**

- Upto 18h\* backup
- MagSnap
- 10mm Drivers
- Call Function
- Voice assistant support
- BT v5.3
- Flexible Neckband
- Type-C Charging
- Built-In Rechargeable Battery
- Rapid Charging (10 min charge for 100 min\* use)
- Environmental Noise Cancellation (ENC)

- Gaming Mode (Low Latency)
- Volume & Media control

### **Specifications:**


Model No.	: ZEB-SNB 2
BT Version	: v5.3
Supported BT Profile	: AVRCP, A2DP
Drive Size	: 10mm
Speaker Impedance	: 32Ω
Playback Time	: 18h*
Charging Time	: 1.5h
Talk Time	: 20h*
Standby Time	: 200h
Package Dimension (W x D x H)	: 18 x 3 x 22 cm
Net. Weight	: 25g

*\* at 50% Volume*

### **Package Content:**

Neckband	: 1 U
Charging Cable	: 1 U
QR Code Guide	: 1 U
Eartips	: 4 U

## Product Representation:



### 1. +Button:

**Single press:** Volume Up

**Long press:** Next Track

### 2. MFB Button:

**Single Press:** Play/Pause

**Long Press:** Voice Assistant

**Double Press:** Redial

**Triple Press:** Gaming Mode/Music Mode

**When Calling (MFB Button on Middle):-**

**Single press:** Pick up/ End The ongoing call

**Long Press:** Direct Incoming call Rejection

### 3. -Button:

**Single Press:** Volume Down

**Long Press:** Previous Track

### 4. LED Indication

1	Charging the Neckband	Red light glows - (charging) Blue Light Glows - Fully charged
2	BT pairing	Red and blue blinks - BT discovery mode Blue blinking - BT paired successfully

## Usage Instruction

**STEP 1** – Separate the earbuds to activate the device. The earbuds will enter pairing mode automatically with Red & Blue LED blinking alternately.

**STEP 2** – Turn ON Bluetooth on your mobile phone and search for the BT name **“ZEB-ESCAPE 90”**

**STEP 3** – Once the BT name is visible in your mobile phone tap to connect it.

## Activating Smart Phone's Voice assistant:

- When the neckband is connected to a mobile phone, Press and hold the **MFB** Button for 3 seconds to activate voice assistant.

## Note:

*Smart phone should have an active internet connection to use the voice assistant function.*

## Power On/Off:

- The **Magsnap** function allows the earbuds to power **Off automatically** when snapped together, and **Power On** when pulled apart.

### **Call Function:**

- Single press the **MFB** button to attend/end the Call and **long** press to reject the incoming call.
- Double press the **MFB** button for Redialing.

### **Charging Instruction:**

- Connect the Type-C charging cable to the charging port of the Neckband & connect the other end to the DC 5V adapter.

### **Gaming & Music mode:**

- Tap the MFB Triple Times to enable gaming mode. To disable gaming mode, again triple times tap MFB to revert to Music Mode.

