



ZEBRONICS
ALWAYS AHEAD

Wireless Neckband Earphone

ZEB **SLINGER**



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-SLINGER**. Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- Avoid the use of this product at the high-temperature and high humidity environment.
- Avoid self-disassemble of product or it will result in the failure of warranty.
- Please charge the product with power adapter output rated voltages DC 5V.

Caution:

Listening at high volumes can cause hearing impairment. Please limit your usage time at high volumes.

Features

Wireless BT earphone with Neckband

Volume/Media Control

Magnetic Earpiece

Call Function

Voice Assistant support

Built-In Rechargeable Battery


Dual Pairing

Specifications

BT Version	: 5.0
Supported BT Profile	: HSP / HFP / A2DP / AVRCP
Drive Size	: 12mm
Speaker Impedance	: 32Ω
Playback Time	: 12 H*
Charging Time	: 2H
Talk Time	: 12 H*
Standby Time	: 480 H
Net Weight	: 19g

** at 50% volume*

Product Representation:



Charging instruction:

Connect micro USB cable to the charging port of the earphone & connect the other end of the cable to a 5V DC adapter.

LED Indication:

Charging Indication: RED LED glows.

Full Charge Indication: RED LED turns BLUE.

BT Discover Mode: Red & Blue LED blinks alternately.

When connected to a phone: Blue LED will blink once in an interval of 5 secs.

Usage Instruction:

Bluetooth Pairing Instruction:

Step 1 : In off state, Long press the MFB button until the earphone goes into pairing mode (Red/Blue LED will blink alternately).

Step 2 : Switch on the Bluetooth on your phone & search for the BT name "**ZEB-SLINGER**".

Step 3 : Once the BT name is shown in the phone, tap to connect it.

Call Function:

Press the MFB Button to answer/hang-up the call. Press and hold the MFB Button for 2 seconds to reject an incoming call.

- Double press the MFB Button to redial the last number dialed.

Music Function:

Press the MFB button to play or pause a music track when playing.

Long press the Vol+ button to skip the Next track, Single press to increase the volume.

Long press the Vol- Button to skip the Prev track, single press to decrease the volume.

Activating Smartphone's Voice Assistant

When the earphone is connected to a smart phone, press and hold the Multi-functional button for 2 seconds to wake up the phone's voice assistant.

ISO 9001:2015 Certified Company

www.zebronics.com

